JVC

Dear Customer,
Thank you for purchasing this digital video camera. Before use, please read the safety information and precautions contained in the pages 2 – 5 to ensure safe use of this product.

ENGLISH

DIGITAL VIDEO CAMERA

GR-D650AS

GETTING STARTED 8

VIDEO RECORDING & PLAYBACK 20

DIGITAL STILL CAMERA (D.S.C.) RECORDING & PLAYBACK 27

ADVANCED FEATURES 32

REFERENCES 47

TERMS Back cover

For Accessories:

http://www.jvc.co.jp/english/accessory/



Mini DV PAL

SD™

MultiMediaCard

To deactivate the demonstration, set "DEMO MODE" to "OFF". (☞ pg. 32, 35)

INSTRUCTIONS

LYT1594-001A

EN

Read This First!

- Before recording important video, be sure to make a trial recording.
  Play back your trial recording to make sure the video and audio have been recorded properly.
- We recommend cleaning your video heads before use.
  If you haven't used your camcorder for awhile, the heads may be dirty. We recommend periodically cleaning the video heads with a cleaning cassette (optional).



- Be sure to store your cassette tapes and camcorder in the proper environment.
  Video heads can become dirty more easily if your cassette tapes and camcorder are stored in a dusty area. Cassette tapes should be removed from the camcorder and stored in cassette cases. Store the camcorder in a bag or other container.
- Use SP (Standard) mode for important video recordings.
  LP (Long Play) mode lets you record 50% more video than SP (Standard) mode, but you may experience mosaic-like noise during playback depending on the tape characteristics and the usage environment.
  So, for important recordings, we recommend using SP mode.
- For safety and reliability.
  It is recommended only genuine JVC batteries and accessories are used in this camcorder.
- This product includes patented and other proprietary technology and will operate only with JVC Data Battery. Use the JVC BN-VF707U/VF714U/VF733U battery packs. Using generic non-JVC batteries can cause damage to the internal charging circuitry.
- This camcorder is designed exclusively for the digital video cassette, SD Memory Card and MultiMediaCard. Only cassettes marked "Mini DV" and memory cards marked "SD" or "*MultiMediaCard*" can be used with this unit.
- Remember that this camcorder is intended for private consumer use only.
  Any commercial use without proper permission is prohibited. (Even if you record an event such as a show, performance or exhibition for personal enjoyment, it is strongly recommended that you obtain permission beforehand.)
- DO NOT leave the unit
  - in place of over 50°C
  - in place where humidity is extremely low (below 35%) or extremely high (80%).
  - in direct sunlight.
  - in a closed car in summer.
  - near a heater.
- The LCD monitor is made with high-precision technology. However, black spots or bright spots of light (red, green or blue) may appear constantly on the LCD monitor. These spots are not recorded on the tape. This is not due to any defect of the unit. (Effective dots: more than 99.99%)
- Do not leave the battery pack attached when the camcorder is not in use and check the unit regularly whether it is working or not.

SAFETY PRECAUTIONS

WARNING: TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS UNIT TO RAIN OR MOISTURE.

CAUTIONS:

- If you notice smoke or a peculiar smell coming from the camcorder or AC Adapter, shut it down and unplug it immediately. Continue using the camcorder or AC Adapter under these conditions could lead to fire or electric shock. Contact your JVC dealer. Do not attempt to repair the malfunction yourself.
- To prevent shock, do not open the cabinet. No user serviceable parts inside. Refer servicing to qualified personnel.
- When you are not using the AC Adapter for a long period of time, it is recommended that you disconnect the power cord from AC outlet.

CAUTION:

To avoid electric shock or damage to the unit, first firmly insert the small end of the power cord into the AC Adapter until it is no longer wobbly, and then plug the larger end of the power cord into an AC outlet.



CAUTIONS:

- This camcorder is designed to be used with PAL-type colour television signals. It cannot be used for playback with a television of a different standard. However, live recording and LCD monitor/viewfinder playback are possible anywhere.
- This product includes patented and other proprietary technology and will operate only with JVC Data Battery. Use the JVC BN-VF707U/VF714U/VF733U battery packs and, to recharge them or to supply power to the camcorder from an AC outlet, use the provided multi-voltage AC Adapter. (An appropriate conversion adapter may be necessary to accommodate different designs of AC outlets in different countries.)

Caution on Replaceable lithium battery

The battery used in this device may present a fire or chemical burn hazard if mistreated.
Do not recharge, disassemble, heat above 100°C or incinerate.
Replace battery with Panasonic (Matsushita Electric), Sanyo, Sony or Maxell CR2025.
Danger of explosion or Risk of fire if the battery is incorrectly replaced.

- Dispose of used battery promptly.
- Keep away from children.
- Do not disassemble and do not dispose of in fire.

NOTES:

- The rating plate (serial number plate) and safety caution are on the bottom and/or the back of the main unit.
- The rating information and safety caution of the AC Adapter are on its upper and lower sides.

When the equipment is installed in a cabinet or on a shelf, make sure that it has sufficient space on all sides to allow for ventilation (10 cm or more on both sides, on top and at the rear).

Do not block the ventilation holes.
(If the ventilation holes are blocked by a newspaper, or cloth etc. the heat may not be able to get out.)

No naked flame sources, such as lighted candles, should be placed on the apparatus.

When discarding batteries, environmental problems must be considered and the local rules or laws governing the disposal of these batteries must be followed strictly.

The apparatus shall not be exposed to dripping or splashing.

Do not use this equipment in a bathroom or places with water.
Also do not place any containers filled with water or liquids (such as cosmetics or medicines, flower vases, potted plants, cups etc.) on top of this unit.
(If water or liquid is allowed to enter this equipment, fire or electric shock may be caused.)

Do not point the lens or the viewfinder directly into the sun. This can cause eye injuries, as well as lead to the malfunctioning of internal circuitry. There is also a risk of fire or electric shock.

CAUTION!

The following notes concern possible physical damage to the camcorder and to the user.

When carrying, be sure to always securely attach and use the provided strap. Carrying or holding the camcorder by the viewfinder and/or the LCD monitor can result in dropping the unit, or in a malfunction.

Take care not to get your finger caught in the cassette holder cover. Do not let children operate the camcorder, as they are particularly susceptible to this type of injury.

Do not use a tripod on unsteady or unlevel surfaces. It could tip over, causing serious damage to the camcorder.

CAUTION!

Connecting cables (Audio/Video, S-Video, etc.) to the camcorder and leaving it on top of the TV is not recommended, as tripping on the cables will cause the camcorder to fall, resulting in damage.

Before Using This Camcorder

Make sure you only use cassettes with the Mini DV mark Mini DV.

Make sure you only use memory cards with the mark SD or MultiMediaCard.
This camcorder is designed exclusively for the digital video cassette, SD Memory Card and MultiMediaCard. Only cassettes marked "Mini DV" and memory cards marked "SD" or "MultiMediaCard" can be used with this unit.

Remember that this camcorder is not compatible with other digital video formats.

Remember that this camcorder is intended for private consumer use only.
Any commercial use without proper permission is prohibited. (Even if you record an event such as a show, performance or exhibition for personal enjoyment, it is strongly recommended that you obtain permission beforehand.)

Before recording important video, be sure to make a trial recording.
Play back your trial recording to make sure the video and audio have been recorded properly.

We recommend cleaning your video heads before use.
If you haven't used your camcorder for a while, the heads may be dirty. We recommend periodically cleaning the video heads with a cleaning cassette (optional).

Be sure to store your cassette tapes and camcorder in the proper environment.
Video heads can become dirty more easily if your cassette tapes and camcorder are stored in a dusty area. Cassette tapes should be removed from the camcorder and stored in cassette cases. Store the camcorder in a bag or other container.

Use SP (Standard) mode for important video recordings.
LP (Long Play) mode lets you record 50% more video than SP (Standard) mode, but you may experience mosaic-like noise during playback depending on the tape characteristics and the usage environment.
So, for important recordings, we recommend using SP mode.

It is recommended that you use JVC brand cassette tapes.
Your camcorder is compatible with all brands of commercially available cassette tapes complying with the MiniDV standard, but JVC brand cassette tapes are designed and optimized to maximize the performance of your camcorder.

Also read "CAUTIONS" on pages 52 – 54.

- Microsoft® and Windows® are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- Macintosh is a registered trademark of Apple Computer, Inc.
- QuickTime is a registered trademark of Apple Computer, Inc.

Major Features of this Camcorder

Wipe/Fader Effects

You can use the Wipe/Fader Effects to make pro-style scene transitions. (☞ pg. 41)



Program AE, Effects and Shutter Effects

For example, “SPORTS” mode allows fast-moving images to be captured one frame at a time, for vivid, stable slow-motion. (☞ pg. 42)



LED Light

You can brighten the subject in the dark place with the LED Light. (☞ pg. 37)



Backlight Compensation

Simply pressing the **BACKLIGHT** button brightens the image darkened by backlight. (☞ pg. 40)

- You can also select a spot metering area so that more precise exposure compensation is available. (☞ pg. 40, Spot Exposure Control)



Data Battery

You can check the battery status by simply pressing the **DATA** button. (☞ pg. 15)



Live Slow

You can record and play back precious or hard-to-see moments at a slow speed. The sound is recorded and played back in real time. (☞ pg. 37)

Auto Button

You can change the recording mode between manual setting to the standard mode setting of the camcorder by pressing the **AUTO** button.



GETTING STARTED 8

Index 8
Provided Accessories 12
Power 14
Operation Mode 16
Language Settings 17
Date/Time Settings 17
Grip Adjustment 18
Viewfinder Adjustment 18
Brightness Adjustment Of The Display 18
Tripod Mounting 18
Loading/Unloading A Cassette 19
Loading/Unloading A Memory Card 19

VIDEO RECORDING & PLAYBACK 20

VIDEO RECORDING 20
Basic Recording 20
Tape Remaining Time 20
LCD Monitor And Viewfinder 20
Zooming 21
Tele Mode 21
Journalistic Shooting 21
Interface Shooting 21
Time Code 22
Quick Review 22
Recording From The Middle Of A Tape 22
VIDEO PLAYBACK 23
Normal Playback 23
Still Playback 23
Shuttle Search 23
Blank Search 23
Connections To A TV Or VCR 24
Playback Using The Remote Control 25

DIGITAL STILL CAMERA (D.S.C.) RECORDING & PLAYBACK 27

D.S.C. RECORDING 27
Basic Shooting (D.S.C. Snapshot) 27
D.S.C. PLAYBACK 28
Normal Playback Of Images 28
Auto Playback Of Images 28
Index Playback Of Files 28
Removing On-Screen Display 28
ADDITIONAL FEATURES FOR D.S.C. 29
Resetting The File Name 29
Protecting Files 29
Deleting Files 30
Setting Print Information (DPOF Setting) 30
Initialising A Memory Card 31

ADVANCED FEATURES 32

MENUS FOR DETAILED ADJUSTMENT 32
Changing The Menu Settings 32
Recording Menus 33
Playback Menus 36
FEATURES FOR RECORDING 37
LED Light 37
Live Slow 37
Wide Mode 37
Night-Scope 38
Snapshot (Record Still Image On Tape) 38
Manual Focus 38
Exposure Control 39
Iris Lock 39
Backlight Compensation 40
Spot Exposure Control 40
White Balance Adjustment 40
Manual White Balance Adjustment 41
Wipe Or Fader Effects 41
Program AE, Effects And Shutter Effects 42
EDITING 43
Dubbing To Or From A VCR 43
Dubbing To Or From A Video Unit Equipped With A DV Connector (Digital Dubbing) 44
Connection To A Personal Computer 45
Audio Dubbing 46
Insert Editing 46

REFERENCES 47

TROUBLESHOOTING 47
USER MAINTENANCE 51
CAUTIONS 52
SPECIFICATIONS 55

TERMS Back cover

Index


⑲
⑩
⑪
26
27
40
22
23
24
28
⑤
⑥
⑦
⑧
⑨
①
32
②
③
④
20
21
1.3xTELE
BLANK
MENU
INDEX
BACKLIGHT
USB
DV
⑫
⑬
33
34
35
36
29
⑭
⑮
⑯
⑰
30
25
31
37
38
⑱
39

Controls

① Rewind Button [◄◄] (☞ pg. 23)
Left Button [<]
Quick Review Button [QUICK REVIEW] (☞ pg. 22)
② Set Button [SET] (☞ pg. 17)
Data Battery Button [DATA] (☞ pg. 15)
③ Stop Button [■] (☞ pg. 23)
Down Button [∨]
Backlight Compensation Button [BACKLIGHT]
④ VIDEO/MEMORY Switch (☞ pg. 16)
⑤ Play/Pause Button [►/II] (☞ pg. 23)
Up Button [∧]
Manual Focus Button [FOCUS] (☞ pg. 38)
⑥ Blank Search [BLANK] (☞ pg. 23)
Tele Mode Button (1.3x TELE) (☞ pg. 21)
⑦ Menu Button [MENU] (☞ pg. 32)
⑧ Fast-Forward Button [►►] (☞ pg. 23)
Right Button [>]
Night Button [NIGHT] (☞ pg. 38)
⑨ Index Button [INDEX] (☞ pg. 28)
LED Light Button [LIGHT]
⑩ Diopter Adjustment Control (☞ pg. 18)
⑪ Auto Button [AUTO] (☞ pg. 16)
⑫ Snapshot Button [SNAPSHOT] (☞ pg. 27, 38)
Live Slow Button (☞ pg. 32, 37)
⑬ Power Zoom Lever [T/W] (☞ pg. 21)
Speaker Volume Control [VOL. +, –] (☞ pg. 23)
⑭ Battery Release Button [PUSH BATT.] (☞ pg. 14)
⑮ Recording Start/Stop Button (☞ pg. 20)
⑯ Power Switch [REC, PLAY, OFF] (☞ pg. 16)
⑰ Lock Button (☞ pg. 16)
⑱ Cassette Open/Eject Switch [OPEN/EJECT] (☞ pg. 19)
⑲ Wide (16:9) Button [16.9] (☞ pg. 37)

Connectors

The connectors are located beneath the covers.
⑳ USB (Universal Serial Bus) Connector (☞ pg. 45)
㉑ Digital Video Connector [DV IN/OUT] (i.LINK*) (☞ pg. 44, 45)
* i.LINK refers to the IEEE1394-1995 industry specification and extensions thereof. The i logo is used for products compliant with the i.LINK standard.
㉒ Audio/Video Input/Output Connector [AV] (☞ pg. 24, 43)
㉓ S-Video Input/Output Connector [S] (☞ pg. 24, 43)
㉔ DC Input Connector [DC] (☞ pg. 14)

Indicators

25 POWER/CHARGE Lamp (☞ pg. 14, 20)

Other Parts

26 LCD Monitor (☞ pg. 20, 21)
27 Viewfinder (☞ pg. 18)
28 Card Cover [▶] (☞ pg. 19)
29 Battery Pack Mount (☞ pg. 14)
30 Shoulder Strap Eyelet (☞ pg. 12)
31 Grip Strap (☞ pg. 18)
32 Speaker (☞ pg. 23)
33 Lens
34 LED Light
35 Camera Sensor
(Be careful not to cover this area, a sensor necessary for shooting is built-in here.)
36 Stereo Microphone
37 Stud Hole (☞ pg. 18)
38 Tripod Mounting Socket (☞ pg. 18)
39 Cassette Holder Cover (☞ pg. 19)
40 Memory Card Slot

LCD Monitor/Viewfinder Indications

During Video Recording Only



①Tape Running Indicator (☞ pg. 20)
(Rotates while tape is running.)
②TELE Mode Indicator (☞ pg. 21)
③Live Slow Indicator (☞ pg. 37)
④Recording Speed Mode (SP/LP) (☞ pg. 33)
(only LP indicator is displayed)
⑤Tape Remaining Time (☞ pg. 20)
⑥REC: (Appears during recording.) (☞ pg. 20)
PAUSE: (Appears during Record-Standby mode.) (☞ pg. 20)
SLOW: (Appears when using Live Slow.)
(☞ pg. 37)
⑦Selected Wipe/Fader Effect Indicator
(☞ pg. 41)
⑧Date/Time (☞ pg. 35)
⑨Time Code (☞ pg. 35)
⑩Digital Image Stabilizer (“DIS”) (☞ pg. 33)
⑪SOUND 12BIT/16BIT: Sound Mode Indicator
(☞ pg. 33) (Appears for approx. 5 seconds after turning on the camcorder.)

During D.S.C. Recording Only



①Image Size: 1280 (1280 x 960), 1024
(1024 x 768) or 640 (640 x 480) (☞ pg. 27)
②Picture Quality: F (FINE) and S
(STANDARD) (in order of quality) (☞ pg. 35)
③Remaining Number Of Shots (☞ pg. 27)
(Displays the approximate remaining number of shots that can be stored during D.S.C. recording.)

During Both Video And D.S.C. Recording



①Battery Remaining Power Indicator
②Operation Mode (☞ pg. 16)
A : Auto Mode
M : Manual Mode
③LED Light Indicator (☞ pg. 37)
④ : Night-Scope Indicator (☞ pg. 38)
A : Gain Up Mode (☞ pg. 34)
⑤Shutter Speed
⑥White Balance Indicator (☞ pg. 40)
⑦Selected Effect Indicator
⑧Selected Program AE Indicator (☞ pg. 42)
⑨Approximate Zoom Ratio (☞ pg. 21)
⑩Zoom Indicator (☞ pg. 21)
⑪Shooting Icon (☞ pg. 27)
(Appears and blinks during shooting.)
⑫Card Icon (☞ pg. 27)
P: Appears during shooting.
M: Blinks in white when a memory card is not loaded.
M: Blinks in yellow while the camcorder is reading the data in the memory card.
⑬**PHOTO**: (Appears when taking Snapshot.)
(☞ pg. 27, 38)
⑭ : Spot Exposure Control Indicator
(☞ pg. 40)
: Backlight Compensation Indicator
(☞ pg. 40)
±: Exposure Adjustment Indicator (☞ pg. 39)
Iris Lock Indicator (☞ pg. 39)
⑮Wind Cut Indicator (☞ pg. 34)
⑯Date (☞ pg. 17)
⑰Manual Focus Adjustment Indicator
(☞ pg. 38)

During 16:9 Recording



The lower side of the screen blackens when "16:9" is selected in Wide Mode (☞ pg. 37). Some of the indicators are displayed on the area.

During Video Playback



①Battery Remaining Power Indicator
②Sound Mode Indicator (☞ pg. 36)
③Blank Search Indicator (☞ pg. 23)
④Tape Speed (SP/LP) (☞ pg. 36)
(only LP indicator is displayed)
⑤►: Playback
►►: Fast-Forward/Shuttle Search
◄◄: Rewind/Shuttle Search
❚❚: Pause
❚❚►: Forward Frame-By-Frame Playback/ Slow-Motion
◄❚❚: Reverse Frame-By-Frame Playback/ Slow-Motion
: Audio Dubbing
❚❚: Audio Dubbing Pause
⑥Date/Time (☞ pg. 36)
⑦VOLUME: Volume Level Indicator (☞ pg. 23)
BRIGHT: Brightness Control Indicator (LCD monitor/Viewfinder) (☞ pg. 18)
⑧Time Code (☞ pg. 36)

During D.S.C. Playback



①Folder/File Number (☞ pg. 28)
②Operation Mode Indicator (☞ pg. 28)
③Brightness Control Indicator (LCD monitor/ Viewfinder) (☞ pg. 18)

Provided Accessories



① AC Adapter AP-V14A
② Power Cord
③ Battery Pack BN-VF707U
④ Audio/Video Cable (ø3.5mini-plug to RCA plug)
⑤ USB Cable
⑥ Core Filter (for USB cable, pg. 13 for attachment)
⑦ CD-ROM
⑧ Remote Control Unit RM-V740U
⑨ Lithium Battery CR2025* (for remote control unit)
⑩ Shoulder Strap (see the right column for attachment)
⑪ Lens Cap (see the right column for attachment)

* A lithium battery is pre-installed in the Remote Control Unit at time of shipment (with insulation sheet). To use the Remote Control Unit, remove the insulation sheet.

NOTES:

- In order to maintain optimum performance of the camcorder, provided cables may be equipped with one or more core filter. If a cable has only one core filter, the end that is closest to the filter should be connected to the camcorder.
- Make sure to use the provided cables for connections. Do not use any other cables.

How To Attach The Lens Cap

To protect the lens, attach the provided lens cap to the camcorder as shown in the illustration.

NOTE:
To confirm the lens cap is on correctly make sure the cap is flush to the camcorder.





How To Attach The Shoulder Strap

Follow the illustration.

1 Thread the strap through the eyelet.

2 Fold it back and thread it through the strap guide and the buckle.

- To adjust the length of the strap, loosen and then tighten the strap in the buckle.

3 Slide the strap guide fully towards the eyelet.



How To Attach The Core Filter

Attach the core filters to the cables. The core filter reduces interference.

1 Release the stoppers on both ends of the core filter.



2 Run the cable through the core filter, leaving approx. 3 cm of cable between the cable plug and the core filter.
Wind the cable once around the outside of the core filter as shown in the illustration.



3 Close the core filter until it clicks shut.



NOTES:

- Take care not to damage the cable.
- When connecting a cable, attach the end with the core filter to the camcorder.

Power

This camcorder's 2-way power supply system lets you choose the most appropriate source of power. Do not use provided power supply units with other equipment.

Charging The Battery Pack



1 Set the Power Switch to "OFF".

2 With the arrow on the battery pack pointing downward, push the battery pack slightly against the battery pack mount ①.

3 Slide down the battery pack until it locks in place ②.

4 Connect the AC Adapter to the camcorder.

5 Connect the Power Cord to AC Adapter.

6 Plug the AC Adapter into an AC outlet. The POWER/CHARGE lamp on the camcorder blinks to indicate charging has started.

7 When the POWER/CHARGE lamp goes out, charging is finished. Unplug the AC Adapter from the AC outlet. Disconnect the AC Adapter from the camcorder.

To detach the battery pack

Slide the battery pack upward while pressing **PUSH BATT.** to detach it.

Battery pack	Charging time
BN-VF707U*	Approx. 1 hr. 30 min.
BN-VF714U	Approx. 2 hrs. 40 min.
BN-VF733U	Approx. 5 hrs. 40 min.

* Provided

NOTES:

- **This product includes patented and other proprietary technology and will operate only with JVC Data Battery. Use the JVC BN-VF707U/VF714U/VF733U battery packs. Using generic non-JVC batteries can cause damage to the internal charging circuitry.**
- If the protective cap is attached to the battery pack, remove it first.
- During charging, the camcorder cannot be operated.
- Charging is not possible if the wrong type of battery is used.
- When charging the battery pack for the first time or after a long storage period, the POWER/CHARGE lamp may not light. In this case, remove the battery pack from the camcorder, then try charging again.
- If a fully charged battery pack is attached to the unit, the POWER/CHARGE lamp does not blink to indicate that charging is not performed.
- If the battery operation time remains extremely short even after having been fully charged, the battery is worn out and needs to be replaced. Please purchase a new one.
- Since the AC Adapter processes electricity internally, it becomes warm during use. Be sure to use it only in well-ventilated areas.
- Using the optional AA-VF7 Battery Charger, you can charge the BN-VF707U/VF714U/VF733U battery pack without the camcorder.
- After 5 minutes has elapsed in Record-Standby mode with the cassette inserted and no operation is performed ("PAUSE" indicator may not appear), the camcorder will automatically turn off its power supplied from the AC adapter. In this case, the battery charge starts if the battery is attached to the camcorder.

Using The Battery Pack

Perform steps **2** – **3** in “Charging The Battery Pack”.

Maximum continuous recording time

Battery pack	LCD monitor on	Viewfinder on
BN-VF707U*	1 hr. 30 min.	1 hr. 40 min.
BN-VF714U	3 hrs. 5 min.	3 hrs. 25 min.
BN-VF733U	7 hrs. 20 min.	8 hrs.

* Provided

NOTES:

- Recording time is reduced significantly under the following conditions:
  - Zoom or Record-Standby mode is engaged repeatedly.
  - The LCD monitor is used repeatedly.
  - The playback mode is engaged repeatedly.
  - The LED Light is used.
- Before extended use, it is recommended that you prepare enough battery packs to cover 3 times the planned shooting time.

ATTENTION:

Before detaching the power source, make sure that the camcorder’s power is turned off. Failure to do so can result in a camcorder malfunction.

Data Battery System

You can check the remaining battery power and the recordable time.

1) Make sure the battery is attached and the Power Switch is set to “OFF”.

2) Open the LCD monitor fully.

3) Press **DATA**, and the battery status screen appears.

- It is displayed for approx. 3 seconds if the button is pressed and released quickly, and for approx. 15 seconds if the button is pressed and hold for several seconds.
- If “COMMUNICATION ERROR” appears instead of the battery status even though you tried to press **DATA** several times, there may be a problem with your battery. In such a case, consult your nearest JVC dealer.

Using AC Power

Perform steps **4** – **6** in “Charging The Battery Pack”.

NOTE:

The provided AC Adapter features automatic voltage selection in the AC range from 110 V to 240 V.

About Batteries

DANGER! Do not attempt to take the batteries apart, or expose them to flame or excessive heat, as it may cause a fire or explosion.
WARNING! Do not allow the battery or its terminals to come in contact with metals, as this can result in a short circuit and possibly start a fire.

To resume the original function of the accurate battery power indication

If the battery power indication differs from the actual operating time, fully charge the battery, and then run it down. However this function may not turn back if the battery was used for a long period of time under extremely high/low temperature condition or charged too many times.

Operation Mode

To turn on the camcorder, set the Power Switch to any operation mode except "OFF" while pressing down the Lock Button located on the switch.



Choose the appropriate operation mode according to your preference using the Power Switch and **VIDEO/MEMORY** Switch.

Power Switch Position
REC: ● Allows you to perform recording on the tape. ● Allows you to set various recording functions using the menus. (☞ pg. 33)
OFF: Allows you to switch off the camcorder.
PLAY: ● Allows you to play back a recording on the tape. ● Allows you to display a still image stored in the memory card or to transfer a still image stored in the memory card to a PC. ● Allows you to set various playback functions using the Menus. (☞ pg. 32)

VIDEO/MEMORY Switch Position
VIDEO: Allows you to record on a tape or play back a tape. If "REC SELECT" is set to "➡ /➡ M" (☞ pg. 35), still images are recorded both on the tape and the memory card.
MEMORY: ● Allows you to record in a memory card or access data stored in a memory card. ● When the Power Switch is set to "REC", the currently selected image size appears.

Auto/Manual Mode

Press **AUTO** button repeatedly to switch to auto/manual recording mode. When manual mode is selected, the indicator "M" appears on the LCD monitor.

Auto Mode : A
You can record using no special effects or manual adjustments.

Manual Mode : M
Manual recording is possible by setting various functions.



Power-Linked Operation

When the Power Switch is set to "REC", you can also turn on/off the camcorder by opening/closing the LCD monitor or pulling out/pushing in the viewfinder.

INFORMATION:
The following explanations in this manual supposes the use of LCD monitor in your operation. If you want to use the viewfinder, close the LCD monitor and pull out the viewfinder fully.

Language Settings

The language on the display can be changed. (☞ pg. 32, 35)

1 Set the Power Switch to "REC" while pressing down the Lock Button located on the switch.

2 Open the LCD monitor fully. (☞ pg. 20)

3 Set the recording mode to "M". (☞ pg. 16)

4 Press **MENU**. The Menu Screen appears.

5 Press ∨, ∧, < or > to select "DISPLAY", and press **SET**. The DISPLAY Menu appears.



6 Press ∨, ∧, < or > to select "LANGUAGE", and press **SET**.

7 Press ∨ or ∧ to select the desired language, and press **SET** or >.

- Press < whenever you want to return to the previous menu screen.



8 Press **MENU**. The Menu Screen closes.

Date/Time Settings

The date/time is recorded onto the tape at all times, but its display can be turned on or off during playback. (☞ pg. 35, 36)

1 Perform steps **1** – **5** in "Language Settings" on the left column.

2 Press ∨, ∧, < or > to select "CLOCK ADJ.", and press **SET**. The date display format is highlighted.



3 Press ∧ or ∨ to select the desired date display format, then press **SET** or >. Select from "MONTH.DATE.YEAR", "DATE.MONTH.YEAR" or "YEAR.MONTH.DATE".

4 Press ∧ or ∨ to select the time display format, then press **SET** or >. Select from "24h" or "12h".

5 Set the year, month, date, hour and minute. Press ∧ or ∨ to select the value, then press **SET** or >. Repeat this step until you have input all the settings.

NOTE:

Press < to return to the previous setting.

6 Press **MENU**. The Menu screen closes.

Grip Adjustment



1 Adjust the velcro strip.

2 Pass your right hand through the loop and grasp the grip.

3 Adjust your thumb and fingers through the grip to easily operate the Recording Start/Stop Button, Power Switch and Power Zoom Lever. Be sure to fasten the velcro strip to your preference.

Viewfinder Adjustment

1 Set the Power Switch to "REC" while pressing down the Lock Button located on the switch.

2 Make sure the LCD monitor is closed and locked. Pull out the viewfinder fully and adjust it manually for best viewability.

3 Turn the Diopter Adjustment Control until the indications in the viewfinder are clearly focused.

Example:



Diopter Adjustment Control

CAUTION:
When retracting the viewfinder, take care not to pinch your fingers.

Brightness Adjustment Of The Display



1 Set the Power Switch to "REC" or "PLAY" while pressing down the Lock Button located on the switch.

2 Open the LCD monitor fully. (☞ pg. 20)

- To adjust the brightness of the viewfinder, pull out the viewfinder fully and set "PRIORITY" to "FINDER" (☞ pg. 32, 34).

3 Press **MENU**. The Menu Screen appears. If you are in Playback mode, please proceed to step **5**.



4 Press ∨, ∧, < or > to select "DISPLAY", and press **SET**. The DISPLAY Menu appears.

5 Press ∨, ∧, < or > to select "BRIGHT", and press **SET**. The Menu Screen closes and the brightness control MENU appears.

6 Press ∨ or ∧ until the appropriate brightness is reached and press **SET** or >.

7 Press **MENU**. The menu screen closes.

Tripod Mounting



To attach the camcorder to a tripod, align the direction stud and screw to the mounting socket and stud hole on the camcorder. Then tighten the screw clockwise.

- Some tripods are not equipped with studs.

Loading/Unloading A Cassette

The camcorder needs to be powered up to load or eject a cassette.



1 Slide and hold **OPEN/EJECT** in the direction of the arrow, then pull the cassette holder cover open until it locks. The cassette holder opens automatically.
- Do not touch internal components.

2 Insert or remove a tape and press "PUSH" to close the cassette holder.
- Be sure to press only the section labeled "PUSH" to close the cassette holder; touching other parts may cause your finger to get caught in the cassette holder, resulting in injury or product damage.
- Once the cassette holder is closed, it recedes automatically. Wait until it recedes completely before closing the cassette holder cover.
- When the battery pack's charge is low, you may not be able to close the cassette holder cover. Do not apply force. Replace the battery pack with a fully charged one or use AC power before continuing.

3 Close the cassette holder cover firmly until it locks into place.

To protect valuable recordings
Slide the erase protection tab on the back of the tape in the direction of "SAVE". This prevents the tape from being recorded over. To record on this tape, slide the tab back to "REC" before loading it.

NOTES:
- If you wait a few seconds and the cassette holder does not open, close the cassette holder cover and try again. If the cassette holder still does not open, turn the camcorder off then on again.
- If the tape does not load properly, open the cassette holder cover fully and remove the cassette. A few minutes later, insert it again.
- When the camcorder is suddenly moved from a cold place to a warm environment, wait a short time before opening the cassette holder cover.

Loading/Unloading A Memory Card



1 Make sure the camcorder's power is off.

2 Open the card cover ( ).

3 **To load a memory card**, firmly insert it with its clipped edge first.
To unload a memory card, push it once. After the memory card comes out of the camcorder, pull it out.
- Do not touch the terminal on the reverse side of the label.

4 Close the card cover.

To protect valuable files (available only for SD Memory Card)
Slide the write/erase protection tab on the side of the memory card in the direction of "LOCK". This prevents the memory card from being recorded over. To record on this memory card, slide the tab back to the position opposite to "LOCK" before loading it.

NOTES:
- Some brands of memory cards are not compatible with this camcorder. Before purchasing a memory card, consult its manufacturer or dealer.
- Before using a new memory card, it is necessary to format the card. (☞ pg. 31)

ATTENTION:
Do not insert or remove the memory card while the camcorder is turned on, as this may cause the memory card to be corrupted or cause the camcorder to become unable to recognise whether or not the card is installed.

Basic Recording

NOTE:
Before continuing, perform the procedures listed below:
- Power (☞ pg. 14)
- Loading A Cassette (☞ pg. 19)



1 Remove the lens cap. (☞ pg. 12)

2 Open the LCD monitor fully.

3 Set the **VIDEO/MEMORY** Switch to "VIDEO".

4 Set the Power Switch to "REC" while pressing down the Lock Button located on the switch.
- The POWER/CHARGE lamp lights and the camcorder enters the Record-Standby mode. "PAUSE" is displayed.
- To record in LP (Long Play) mode, ☞ pg. 33.

5 To start recording, press the Recording Start/Stop Button. "REC" appears on the display while recording is in progress.

6 To stop recording, press the Recording Start/Stop Button again. The camcorder re-enters the Record-Standby mode.

Approximate recording time

Tape	Recording mode	
	SP	LP
30 min.	30 min.	45 min.
60 min.	60 min.	90 min.
80 min.	80 min.	120 min.

NOTES:
- If the Record-Standby mode continues for 5 minutes and no operation is performed (PAUSE indicator may not appear), the camcorder's power shuts off automatically. To turn the camcorder on again, push back and pull out the viewfinder again or close and re-open the LCD monitor.
- When a blank portion is left between recorded scenes on the tape, the time code is interrupted and errors may occur when editing the tape. To avoid this, refer to "Recording From The Middle Of A Tape" (☞ pg. 22).
- To turn the melody sounds off, ☞ pg. 34.

Tape Remaining Time



Approximate tape remaining time appears on the display. "– – – min" means the camcorder is calculating the remaining time. When the remaining time reaches 2 minutes, the indication starts blinking.
- The time required to calculate and display the remaining tape length, and the accuracy of the calculation, may vary according to the type of tape used.

LCD Monitor And Viewfinder

While using the LCD monitor:
Make sure the viewfinder is pushed back in. Pull on the end Ⓐ of the LCD monitor and open the LCD monitor fully. It can rotate 270° (90° downward, 180° upward).



While using the viewfinder:
Make sure the LCD monitor is closed and locked. Pull out the viewfinder fully.

NOTES:
- The image will not appear simultaneously on the LCD monitor and the viewfinder. When the viewfinder is pulled out while the LCD monitor is opened, you can select which one to use. Set "PRIORITY" to the desired mode in SYSTEM Menu. (☞ pg. 34)
- Coloured bright spots may appear all over the LCD monitor or the viewfinder. However, this is not a malfunction. (☞ pg. 48)

Zooming

Produces the zoom in/out effect, or an instantaneous change in image magnification.

Zoom In
Slide the Power Zoom Lever towards “T”.

Zoom Out
Slide the Power Zoom Lever towards “W”.
- The further you slide the Power Zoom Lever, the quicker the zoom action.



NOTES:
- Focusing may become unstable during Zooming. In this case, set the zoom while in Record-Standby, lock the focus by using the manual focus (☞ pg. 38), then zoom in or out in Record mode.
- Zooming is possible to a maximum of 700X, or it can be switched to 15X magnification using the optical zoom. (☞ pg. 34)
- Zoom magnification of over 15X is done through Digital image processing, and is therefore called Digital Zoom.
- During Digital zoom, the quality of image may suffer.
- Digital zoom cannot be used when the **VIDEO**/**MEMORY** Switch is set to “MEMORY”.
- Macro shooting (as close as approx. 5 cm to the subject) is possible when the Power Zoom Lever is set all the way to “W”. Also see “TELE MACRO” in FUNCTION Menu on page 33.
- When shooting a subject close to the lens, zoom out first. If zoomed-in in the auto focus mode, the camcorder may automatically zoom out depending on the distance between the camcorder and the subject. This will not occur when “TELE MACRO” is set to “ON”. (☞ pg. 33)

Tele Mode

Performs instant clear zoom to an image during recording or record/standby mode.



Press **1.3x TELE** alternately during recording or record/standby mode to switch to OFF/ON. When you select “TELE ON”. The Tele Mode indicator “TELE” appears.

NOTES:
- Available only when the **VIDEO**/**MEMORY** Switch is set to “VIDEO”.
- Tele mode cannot be used when the 16:9 wide mode (16:9 indicator) is selected.

Journalistic Shooting

In some situations, different shooting angles may provide more dramatic results. Hold the camcorder in the desired position and tilt the LCD monitor in the most convenient direction. It can rotate 270° (90° downward, 180° upward).



Interface Shooting

The person you shoot can view himself/herself in the LCD monitor, and you can even shoot yourself while viewing your own image in the LCD monitor.
1) Open the LCD monitor and tilt it upward to 180° so that it faces forward. Then, pull out the viewfinder fully.
2) Point the lens toward the subject (yourself when self-recording) and start recording.

- During Interface Shooting, the monitor image appears inverted as it would when viewing a mirror. However, the actual recorded image does not appear inverted.
- If the Quick Review (☞ pg. 22) is executed during the interface shooting, the LCD monitor will be turned off. In such a case, check the playback picture in the viewfinder. To check the playback picture in the LCD monitor, close the viewfinder.

Time Code

During recording, a time code is recorded on the tape. This code is to confirm the location of the recorded scene on the tape during playback.

Display



* Frames are not displayed during recording.

If recording starts from a blank portion, the time code begins counting from “00:00:00” (minute:second:frame). If recording starts from the end of a previously recorded scene, the time code continues from the last time code number. If during recording a blank portion is left partway through the tape, the time code is interrupted. When recording is resumed, the time code starts counting up again from “00:00:00”. This means the camcorder may record the same time codes as those existing in a previously recorded scene. To prevent this, perform Recording From The Middle Of A Tape (☞ pg. 22) in the following cases;

- When shooting again after playing back a recorded tape.
- When power shuts off during shooting.
- When a tape is removed and re-inserted during shooting.
- When shooting using a partially recorded tape.
- When shooting on a blank portion located partway through the tape.
- When shooting again after shooting a scene then opening/closing the cassette holder cover.

NOTES:

- The time code cannot be reset.
- During fast-forwarding and rewinding, the time code indication does not move smoothly.
- The time code is displayed only when “TIME CODE” is set to “ON”. (☞ pg. 35)

Quick Review

Enables to check the end of the last recording.
1) Press **QUICK REVIEW** during the Recording-Standby mode.
2) Tape is rewound for about several seconds and played back automatically, then pauses in the Recording-Standby mode for the next shot.

- Distortion may occur at start of playback. This is normal.

Recording From The Middle Of A Tape

1) Play back a tape or use Blank Search (☞ pg. 23) to find the spot at which you want to start recording, then engage the Still Playback mode. (☞ pg. 23)
2) Set the Power Switch to “REC” while pressing down the Lock Button located on the switch, then start recording.

Normal Playback



1 Load a cassette. (☞ pg. 19)

2 Set the **VIDEO/MEMORY** Switch to "VIDEO".

3 Set the Power Switch to "PLAY" while pressing down the Lock Button located on the switch.

4 To start playback, press ►/II.

5 To stop playback, press ■.

- During Stop mode, press ◄◄ to rewind, or ►► to fast-forward the tape.

To control the speaker volume

Slide the Power Zoom Lever (**VOL. +/–**) towards "**+**" to turn up the volume, or towards "**–**" to turn down the volume.

NOTES:

- The playback picture can be viewed in the LCD monitor, viewfinder or on a connected TV. (☞ pg. 24)
- If Stop mode continues for 5 minutes when power is supplied from a battery, the camcorder shuts off automatically. To turn on again, set the Power Switch to "OFF", then to "PLAY".
- When a cable is connected to the AV connector, the sound is not heard from the speaker.

Still Playback

Pauses during video playback.

1) Press ►/II during playback.

2) To resume normal playback, press ►/II again.

- If still playback continues for more than about 3 minutes, the camcorder's Stop mode is automatically engaged.

Shuttle Search

Allows high-speed search in either direction during video playback.

1) During playback, press ►► for forward search, or ◄◄ for reverse search.

2) To resume normal playback, press ►/II.

- During playback, press and hold ►► or ◄◄. The search continues as long as you hold the button. Once you release the button, normal playback resumes.
- A slight mosaic effect appears on the display during Shuttle Search. This is not a malfunction.

ATTENTION:

During Shuttle Search, parts of the picture may not be clearly visible, particularly on the left side of the screen.

Blank Search

Helps you find where you should start recording in the middle of a tape to avoid time code interruption. (☞ pg. 22)

1 Load a cassette. (☞ pg. 19)

2 Set the **VIDEO/MEMORY** Switch to "VIDEO".

3 Set the Power Switch to "PLAY" while pressing down the Lock Button located on the switch.

4 Press **BLANK**.

- The "BLANK SEARCH" indication appears and the camcorder automatically starts reverse or forward search, then stops at the spot which is about 3 seconds of tape before the beginning of the detected blank portion.
- To cancel Blank Search, press ■ or **BLANK**.

NOTES:

- Before starting Blank Search, if the current position is at a blank portion, the camcorder searches in the reverse direction. If the current position is at a recorded portion, the camcorder searches in the forward direction.
- If the beginning or end of the tape is reached during Blank Search, the camcorder stops automatically.
- A blank portion which is shorter than 5 seconds of tape may not be detected.
- The detected blank portion may be located between recorded scenes. Before you start recording, make sure there is no recorded scene after the blank portion.

Connections To A TV Or VCR



❶ Yellow to VIDEO IN (Connect when your TV/VCR has only A/V input connectors.)
❷ Red to AUDIO R IN*
❸ White to AUDIO L IN*
❹ To S-VIDEO IN (Connect when your TV/VCR has S-VIDEO IN and AV input connectors. In this case, it is not necessary to connect the yellow video cable.)

* Not required for watching still images only.

1 Make sure all units are turned off.

2 Connect the camcorder to a TV or VCR as shown in the illustration.

If using a VCR, go to step **3**.
If not, go to step **4**.

3 Connect the VCR output to the TV input, referring to your VCR's instruction manual.

4 Turn on the camcorder, the VCR and the TV.

5 Set the VCR to its AUX input mode, and set the TV to its VIDEO mode.

6 Start playback on the camcorder. (☞ pg. 23)

To choose whether or not the following displays appear on the connected TV

- Date/Time
  Set "DATE/TIME" to "ON" or "OFF". (☞ pg. 32, 36)
  Or, press **DISPLAY** on the remote control to turn on/off the date indication.
- Time Code
  Set "TIME CODE" to "ON" or "OFF". (☞ pg. 32, 36)
- Indications other than date/time and time code
  Set "ON SCREEN" to "OFF", "LCD" or "LCD/TV". (☞ pg. 32, 36)

NOTES:

- **It is recommended to use the AC Adapter as the power supply instead of the battery pack. (☞ pg. 15)**
- To monitor the picture and sound from the camcorder without inserting a tape or memory card, set the camcorder's Power Switch to "REC", then set your TV to the appropriate input mode.
- Make sure you adjust the TV sound volume to its minimum level to avoid a sudden burst of sound when the camcorder is turned on.

Playback Using The Remote Control

The Full-Function Remote Control Unit can operate this camcorder from a distance as well as the basic operations (Playback, Stop, Pause, Fast-Forward and Rewind) of your VCR. It also makes additional playback functions possible. (☞ pg. 26)

Installing The Battery

The remote control uses one lithium battery (CR2025).



Lock tab

1 Pull out the battery holder by pushing the lock tab.

2 Insert the battery in the holder, and be sure to have the "+" mark visible.

3 Slide the holder back in until you hear a click.

Beam Effective Area (indoor use)

When using the remote control, be sure to point it at the remote sensor. The transmitted beam's approximate effective distance for indoor use is 5 m.


Remote sensor

NOTE:

The transmitted beam may not be effective or may cause incorrect operation when the remote sensor is directly exposed to sunlight or powerful lighting.

Buttons And Functions



❶ Infrared beam transmitting window
- Transmits the beam signal.

The following buttons are available only when the camcorder's Power Switch is set to "PLAY".

❷ PAUSE Button
- Pauses the tape (☞ pg. 26)

Up Button (☞ pg. 26)

❸ SLOW Rewind Button (☞ pg. 26)

❹ REW Button
- Rewind/Reverse Shuttle Search on a tape (☞ pg. 23)
- Displays previous file in a memory card (☞ pg. 28)

Left Button (☞ pg. 26)

❺ INSERT Button (☞ pg. 46)

❻ SHIFT Button (☞ pg. 26)

❼ DISPLAY Button (☞ pg. 24, 43)

❽ SLOW Forward Button (☞ pg. 26)

❾ PLAY Button
- Starts Playback of a tape (☞ pg. 23)
- Starts Auto Playback of images in a memory card (☞ pg. 28)

❿ FF Button
- Forward/Forward Shuttle Search on a tape (☞ pg. 23)
- Displays next file in a memory card (☞ pg. 28)

Right Button (☞ pg. 26)

⓫ A. DUB Button (☞ pg. 46)

⓬ STOP Button
- Stops the tape (☞ pg. 23)
- Stops Auto Playback (☞ pg. 28)

Down Button (☞ pg. 26)

⓭ EFFECT Button (☞ pg. 26)

⓮ EFFECT ON/OFF Button (☞ pg. 26)

The following buttons are available when the camcorder's Power Switch is set to "REC".

⓯ Zoom (T/W) Buttons
Zoom in/out (☞ pg. 21, 26)
(Also available with the Power Switch set to "PLAY")

⓰ START/STOP Button
Functions the same as the Recording Start/Stop Button on the camcorder.

⓱ S.SHOT Button
Functions the same as **SNAPSHOT** on the camcorder.
(Also available with the Power Switch set to "PLAY")



Slow-Motion Playback

During normal video playback, press **SLOW** (◀‖ or ‖▶) more than approx. 2 seconds.
- After approx. 10 minutes, normal playback resumes.
- To pause Slow-Motion playback, press **PAUSE** (PAUSE).
- To stop Slow-Motion playback, press **PLAY** (►).

NOTES:
- You can also engage Slow-Motion Playback from Still Playback by pressing **SLOW** (◀‖ or ‖▶) more than approx. 2 seconds.
- During Slow-Motion Playback, due to digital image processing, the picture may take on a mosaic effect.
- After **SLOW** (◀‖ or ‖▶) is pressed and held, the still image may be displayed for a few seconds, followed by a blue screen for a few seconds. This is not a malfunction.
- During Slow-Motion Playback, there will be disturbances in video and the picture may seem unstable, especially with steady images. This is not a malfunction.

Frame-By-Frame Playback

During normal or still playback, press **SLOW** (‖▶) repeatedly for forward or **SLOW** (◀‖) repeatedly for reverse. Each time **SLOW** (◀‖ or ‖▶) is pressed, the frame is played back.

Playback Zoom

Magnifies the recorded image up to 47X at any time during video playback and D.S.C. playback.

1) Press **PLAY** (►) to start video playback. Or perform normal playback of images.

2) At the point you want to zoom in, press the Zoom Button (**T**).
- To zoom out, press the Zoom Button (**W**).

3) You can move the image on the screen around to find a particular portion of the picture. While holding down **SHIFT**, press ◁ (Left), ▷ (Right), △ (Up) and ▽ (Down).

- To end zoom, press and hold **W** until magnification returns to normal. Or, press **STOP** (■) and then press **PLAY** (►) during video playback.
- To end zoom during D.S.C. playback, press **PLAY** (►).

NOTES:
- Zoom can also be used during slow-motion and still playback.
- Due to digital image processing, the quality of the image may suffer.

Playback Special Effects

Allows you to add creative effects to the video playback image.

SEPIA: Recorded scenes have a brownish tint like old photos.

MONOTONE: Like classic black and white films, your footage is shot in B/W. Used together with the Cinema mode, it enhances the “classic film” effect.

CLASSIC: Gives recorded scenes a strobe effect.

STROBE: Your recording looks like a series of consecutive snapshots.

1) To start playback, press **PLAY** (►).



2) Press **EFFECT**. The PLAYBACK EFFECT Select Menu appears.

3) Press **EFFECT** repeatedly to move the highlight bar to the desired effect.
- The selected function is activated and after 2 seconds the menu disappears.
- To deactivate the selected effect, press **EFFECT ON/OFF**. To reactivate the selected effect press **EFFECT ON/OFF** again.
- To change the selected effect, repeat from step **2** above.

Basic Shooting (D.S.C. Snapshot)

You can use your camcorder as a Digital Still Camera for taking snapshots. Still images are stored in the memory card.

NOTE:

Before continuing, perform the procedures listed below:

- Power (☞ pg. 14)
- Loading a Memory Card (☞ pg. 19)



1 Remove the lens cap.

2 Open the LCD monitor fully. (☞ pg. 20)

3 Set the **VIDEO/MEMORY** Switch to "MEMORY".

4 Set the Power Switch to "REC" while pressing down the Lock Button located on the switch.

- To change the Image Size and/or Picture Quality, ☞ pg. 32, 35.

5 Press **SNAPSHOT**. The "**PHOTO**" indication appears while the snapshot is being taken.

- To delete unwanted still images, refer to "Deleting Files". (☞ pg. 30)
- When you do not want to hear the shutter sound, set "MELODY" to "OFF". (☞ pg. 32, 34)

NOTE:

If shooting is not performed for approx. 5 minutes when the Power Switch is set to "REC" and power is supplied from the battery pack, the camcorder shuts off automatically to save power. To perform shooting again, push back and pull out the viewfinder again or close and re-open the LCD monitor.

Approximate Number of Storable Images

- The number increases or decreases depending on the Picture Quality/Image Size, etc.

Image Size/Picture Quality	SD Memory Card*			
	8 MB	16 MB	32 MB	64 MB
640 x 480/FINE	47	95	205	425
640 x 480/STANDARD	160	295	625	1285
1024 x 768/FINE	21	47	95	200
1024 x 768/STANDARD	65	145	310	640
1280 x 960/FINE	13	29	60	125
1280 x 960/STANDARD	45	95	205	425

Image Size/Picture Quality	MultiMediaCard*		
	8 MB	16 MB	32 MB
640 x 480/FINE	55	105	215
640 x 480/STANDARD	190	320	645
1024 x 768/FINE	25	50	100
1024 x 768/STANDARD	75	160	320
1280 x 960/FINE	16	32	60
1280 x 960/STANDARD	50	105	216

* Optional

Normal Playback Of Images

Images shot with the camcorder are automatically numbered, then stored in numerical order in the memory card. You can view the stored images, one at a time, much like flipping through a photo album.



1 Load a memory card. (☞ pg. 19)

2 Set the **VIDEO/MEMORY** Switch to "MEMORY".

3 Set the Power Switch to "PLAY" while pressing down the Lock Button located on the switch.
- A stored image is displayed.

4 Press < to display the previous file. Press > to display the next file.

NOTE:
Images shot and stored on the card with another device with resolutions other than "640 x 480" and "1024 x 768" will be displayed as thumbnails only. These thumbnail images cannot be transferred to a PC.

Playback Zoom

Available only with the remote control.
(☞ pg. 26)

Auto Playback Of Images

You can run through all the images stored in memory card automatically.

1 Perform steps **1** – **3** in "Normal Playback Of Images".

2 Press ►/II to start Auto Playback.
- If you press < during Auto Playback, files are displayed in descending order.
- If you press > during Auto Playback, files are displayed in ascending order.

3 To end Auto Playback, press ■.

Index Playback Of Files

You can view several different files stored in the memory card at a time. This browsing capability makes it easy to locate a particular file you want.

1 Perform steps **1** – **3** in "Normal Playback Of Images" (see the left column).

2 Press **INDEX**. The Index Screen appears.

3 Press ∨, ∧, < or > to move the frame to the desired file.

4 Press **SET**. The selected file is displayed.



Removing On-Screen Display

1 Perform steps **1** – **3** in "Normal Playback Of Images" (see the left column).

2 Press **MENU**. The Menu Screen appears.

3 Press ∨, ∧, < or > to select "ON SCREEN", and press **SET**. The ON SCREEN Menu appears.

4 Press ∨ or ∧ to select "OFF", and press **SET** or >, then press **MENU**. The operation mode indicator and folder/file number disappear.
- To display the indicators again, select "ON".



Resetting The File Name

By resetting the file name, a new folder will be made. The new files you are going to make will be stored in the new folder. It is convenient to separate the new files from previously made files.

1 Perform steps **1** – **3** in "Normal Playback Of Images". (☞ pg. 28)

2 Press **MENU**. The Menu Screen appears.

3 Press ∨, ∧, < or > to select "NO. RESET", and press **SET**. The NO. RESET screen appears.

4 Press ∨ or ∧ to select "EXECUTE", and press **SET**. The new folder (such as "101JVCGR") will be made and the file name of the next shot starts from DVC00001.

NOTE:

If the file name reaches DVC09999, a new folder (such as "101JVCGR") will be made and the file name will start again from DVC00001.

Protecting Files

The Protect mode helps prevent the accidental erasure of files.

1 Perform steps **1** – **3** in "Normal Playback Of Images". (☞ pg. 28)

2 Press **MENU**. The Menu Screen appears.

3 Press ∨, ∧, < or > to select "PROTECT", and press **SET**. The PROTECT Menu appears.

To protect the currently displayed file

4 Press ∨ or ∧ to select "CURRENT", and press **SET** or >. The PROTECT screen appears.



5 Press < or > to select the desired file.

6 Press ∨ or ∧ to select "EXECUTE", and press **SET**.

- To cancel protection, select "RETURN".
- Repeat steps **5** and **6** for all files you want to protect.

To protect all files stored in the memory card

4 Press ∨ or ∧ to select "PROT.ALL", and press **SET** or >. The PROTECT screen appears.

5 Press ∨ or ∧ to select "EXECUTE", and press **SET**.

- To cancel protection, select "RETURN".

NOTES:

- If the "⚿" mark appears, the currently displayed file is protected.
- When the memory card is initialised or corrupted, even protected files are deleted. If you do not want to lose important files, transfer them to a PC and save them.

To Remove Protection

Before doing the following, perform steps **1** – **3** in "Protecting Files".

To remove protection from the currently displayed file

4 Press ∨ or ∧ to select "CURRENT", and press **SET** or >. The PROTECT screen appears.



5 Press < or > to select the desired file.

6 Press ∨ or ∧ to select "EXECUTE", and press **SET**.

- To cancel selection, select "RETURN".
- Repeat steps **5** and **6** for all files you want to remove protection.

To remove protection from all files stored in the memory card

4 Press ∨ or ∧ to select "CANC.ALL", and press **SET** or >. The PROTECT screen appears.

5 Press ∨ or ∧ to select "EXECUTE", and press **SET**.

- To cancel selection, select "RETURN".

Deleting Files

Previously stored files can be deleted either one at a time or all at once.

1 Perform steps **1** – **3** in "Normal Playback Of Images" (☞ pg. 28).

2 Press **MENU**. The Menu Screen appears.

3 Press ∨, ∧, < or > to select "DELETE", and press **SET**. The Menu appears.

To delete the currently displayed file

4 Press ∨ or ∧ to select "CURRENT", and press **SET** or >. The DELETE screen appears.



5 Press < or > to select the desired file.

6 Press ∨ or ∧ to select "EXECUTE", and press **SET**.

- To cancel deletion, select "RETURN".
- Repeat steps **5** and **6** for all files you want to delete.



NOTE:

If the "⚿" mark appears, the selected file is protected and cannot be deleted.

To delete all files stored in the memory card

4 Press ∨ or ∧ to select "ALL", and press **SET** or >. The DELETE screen appears.

5 Press ∨ or ∧ to select "EXECUTE", and press **SET**.

- To cancel deletion, select "RETURN".

NOTES:

- Protected files (☞ pg. 29) cannot be deleted. To delete them, remove protection first.
- Once files are deleted, they cannot be restored. Check files before deleting.

CAUTION:

Do not remove the memory card or perform any other operation (such as turning off the camcorder) during deletion. Also, be sure to use the provided AC Adapter, as the memory card may be corrupted if the battery becomes exhausted during deletion. If the memory card becomes corrupted, initialise it. (☞ pg. 31)

Setting Print Information (DPOF Setting)

This camcorder is compatible with the DPOF (Digital Print Order Format) standard in order to support future systems such as automatic printing. You can select one of the 2 print information settings for images stored in the memory card: "To Print All Still Images (One Print For Each)" or "To Print By Selecting Still Images And Number Of Prints".

NOTE:

If you load a memory card already set as shown below in a printer compatible with DPOF, it will make prints of the selected still images automatically.

To Print All Still Images (One Print For Each)

1 Perform steps **1** – **3** in "Normal Playback Of Images". (☞ pg. 28)

2 Press **MENU**. The Menu Screen appears.

3 Press ∨, ∧, < or > to select "DPOF", and press **SET**. The DPOF Menu appears.



4 Press ∨ or ∧ to select "ALL 1", and press **SET** or >. The DPOF screen appears.

5 Press ∨ or ∧ to select "EXECUTE", and press **SET**. The normal playback screen appears.

- To cancel selection, select "RETURN".



To Print By Selecting Still Images And Number Of Prints

1 Perform steps **1** – **3** in "To Print All Still Images (One Print For Each)". (☞ pg. 30)

2 Press ∨ or ∧ to select "CURRENT", and press **SET** or >. The DPOF screen appears.

3 Press < or > to select the desired file.

4 Press ∨ or ∧ to select the number indication (00), and press **SET**.

5 Select the number of prints by pressing ∧ to increase the number, or ∨ to decrease the number, and press **SET**.



- Repeat steps **3** through **5** for the desired number of prints.
- The number of prints can be set up to 15.
- To correct the number of prints, select the image again and change the number.

6 Press ∨ or ∧ to select "RETURN", and press **SET**. The "SAVE?" appears.



- If you did not change any settings in step **3** through **5**, the DPOF Menu reappears.

7 Press ∨ or ∧ to select "EXECUTE" to save the setting you have just made, and press **SET**.

- To cancel selection, select "CANCEL".

To Reset The Number Of Prints

1 Perform steps **1** – **3** in "To Print All Still Images (One Print For Each)". (☞ pg. 30)

2 Press ∨ or ∧ to select "RESET", and press **SET** or >. The DPOF screen appears.

3 Press ∨ or ∧ to select "EXECUTE", and press **SET**. The normal playback screen appears.

- To cancel selection, select "RETURN".
- The number of prints is reset to 0 for all still images.

CAUTION:
While performing the above, never disconnect power, as this may cause the memory card to be corrupted.

Initialising A Memory Card

You can initialise a memory card any time. After initialising, all files and data stored in the memory card, including those which have been protected, are cleared.

1 Set the **VIDEO**/**MEMORY** Switch to "MEMORY".

2 Set the Power Switch to "PLAY" while pressing down the Lock Button located on the switch.

3 Press **MENU**. The Menu Screen appears.

4 Press ∨, ∧, < or > to select "FORMAT", and press **SET**. The FORMAT screen appears.

5 Press ∨ or ∧ to select "EXECUTE", and press **SET**. The memory card is initialised.



- When initialisation is finished, "NO IMAGES STORED" appears.
- To cancel initialisation, select "RETURN".

CAUTION:
Do not perform any other operation (such as turning off the camcorder) during initialisation. Also, be sure to use the provided AC Adapter, as the memory card may be corrupted if the battery becomes exhausted during initialisation. If the memory card becomes corrupted, initialize it.

Changing The Menu Settings

This camcorder is equipped with an easy-to-use, on-screen menu system that simplifies many of the more detailed camcorder settings.
(☞ pg. 32 – 36)



1 For Video and D.S.C. Recording Menus:
- Set the **VIDEO/MEMORY** Switch to "VIDEO" or "MEMORY".
- Set the Power Switch to "REC" while pressing down the Lock Button located on the switch.
- Set the recording mode to "M". (☞ pg. 16)

For Video Playback Menu:
- Set the **VIDEO/MEMORY** Switch to "VIDEO".
- Set the Power Switch to "PLAY" while pressing down the Lock Button located on the switch.
- For D.S.C. Playback Menu, refer to "D.S.C. PLAYBACK" (☞ pg. 28).

2 Open the LCD monitor fully. (☞ pg. 20)

3 Press **MENU**. The Menu Screen appears.

4 Press ∨, ∧, < or > to select the desired function, and press **SET**. The selected function menu appears.

Screen for Video and D.S.C. Recording Menu



Screen for Video Playback Menu



5 Setting procedure hereafter depends on the selected function.

NOTES:
- You cannot enter Menu Screen during recording.
- Certain functions cannot be set in the Video or D.S.C. Recording Menus. These icons will be displayed in grey/white.

Video Recording and D.S.C. Recording Menus

FUNCTION (☞ pg. 33)
SETTING (☞ pg. 33)
SYSTEM (☞ pg. 34)
DISPLAY (☞ pg. 35)
DSC (☞ pg. 35)

Selected menu icon



1) Press ∨, ∧, < or > to select the desired selection and press **SET**.
- Example: WIPE/FADER Menu.
- Press to return to the Main Menu screen.

2) Press ∨ or ∧ to select the desired parameter and press **SET** or >. Selection is complete.
- The "►" indicator shows the setting that is currently saved inside the camcorder's memory.
- Press < whenever you want to cancel or return to the previous Menu Screen.

3) Press **MENU**. The Menu Screen closes.

NOTE:
Repeat the procedure if you wish to set other function menus.

Video Playback Menu

REC MODE (☞ pg. 36)
SOUND MODE (☞ pg. 36)
NARRATION (☞ pg. 36)
S/AV INPUT (☞ pg. 36)
BRIGHT (☞ pg. 36)
DATE/TIME (☞ pg. 36)
ON SCREEN (☞ pg. 36)
TIME CODE (☞ pg. 36)
16:9 (☞ pg. 36)

Selected menu icon



"►" indicator



Example: REC MODE Menu

1) Press ∨ or ∧ to select the desired parameter and press **SET** or >. Selection is complete.
- Repeat the procedure if you wish to set other function menus.
- The "►" indicator shows the setting that is currently saved inside the camcorder's memory.
- Press < whenever you want to cancel or return to the previous Menu Screen.

2) Press **MENU**. The Menu Screen closes.

Recording Menus

FUNCTION

The following menu settings can be changed only when the Power Switch is set to “REC”.
[ ] = Factory-preset

WIPE/FADER

(☞ pg. 41), “Wipe or Fader Effects”

EFFECT

(☞ pg. 42), “Program AE, Effects and Shutter Effects”

PROGRAM AE

(☞ pg. 42), “Program AE, Effects and Shutter Effects”

SHUTTER

(☞ pg. 42), “Program AE, Effects and Shutter Effects”

EXPOSURE

(☞ pg. 39), “Exposure Control”

W. BALANCE

(☞ pg. 40), “White Balance Adjustment”

TELE MACRO

[OFF]: Disables the function.
ON: When the distance to the subject is less than 1 m, set “TELE MACRO” to “ON”. You can shoot a subject as large as possible at a distance of approx. 40 cm.
Depending on the zoom position, the lens may go out of focus.

SETTING

The following settings are effective when the Power Switch is set to “REC”.
[ ] = Factory-preset

REC MODE

[SP]*: To record in the SP (Standard Play) mode
LP: Long Play—more economical, providing 1.5 times the recording time.
* SP indicator does not appear on the screen.

NOTES:

- Audio Dubbing (☞ pg. 46) and Insert Editing (☞ pg. 46) are possible on tapes recorded in the SP mode.
- If the recording mode is switched, the playback picture will be blurred at the switching point.
- It is recommended that tapes recorded in the LP mode on this camcorder be played back on this camcorder.
- During playback of a tape recorded on another camcorder, blocks of noise may appear or there may be momentary pauses in the sound.

SOUND MODE

[12BIT]: Enables video recording of stereo sound on four separate channels, and is recommended for use when performing Audio Dubbing. (Equivalent to the 32 kHz mode of previous models)
16BIT: Enables video recording of stereo sound on two separate channels. (Equivalent to the 48 kHz mode of previous models)

DIS*

OFF: Disables the function.
[ON ( )]: To compensate for unstable images caused by camera-shake, particularly at high magnification.

NOTES:

- Accurate stabilisation may not be possible if hand shake is excessive, or depending on the shooting condition.
- The “( )” indicator blinks or goes out if the Stabiliser cannot be used.
- Switch off this mode when recording with the camcorder on a tripod.

* Available only when the **VIDEO/MEMORY** Switch is set to “VIDEO”.

SNAP/SLOW*

[SNAP]: Snapshot mode
SLOW : Live Slow mode
For details on the procedure, refer to “Live Slow” (☞ pg. 37) and “Snapshot (Record Still Image On Tape)” (☞ pg. 38).

* Available only when the **VIDEO**/**MEMORY** Switch is set to “VIDEO”.

ZOOM*

[15X]: When set to “15X” while using digital zoom, the zoom magnification will reset to 15X since digital zoom will be disengaged.
60X*: Allows you to use the Digital Zoom. By digitally processing and magnifying images, zooming is possible from 15X (the optical zoom limit), to a maximum of 60X digital magnification.
700X*: Allows you to use the Digital Zoom. By digitally processing and magnifying images, zooming is possible from 15X (the optical zoom limit), to a maximum of 700X digital magnification.

* Available only when the **VIDEO**/**MEMORY** Switch is set to “VIDEO”.

GAIN UP

OFF: Allows you to shoot dark scenes with no picture brightness adjustment.
[AGC]: The overall appearance may be grainy, but the image is bright.
AUTO **A** : The shutter speed is automatically adjusted. Shooting a subject in low or poor lighting at slow shutter speed provides a brighter image than in the AGC mode, but the subject’s movements are not smooth or natural. The overall appearance may be grainy. While the shutter speed is being automatically adjusted, “**A**” is displayed.

WIND CUT

[OFF]: Disengages the function.
ON : Helps cut down on noise created by wind. The “ ” indicator appears. The quality of the sound will change. This is normal.

16:9

To enable your tv to display images in 16:9 wide mode, set the tv screen size correctly.
[4:3TV]: For TV with an aspect ratio of 4:3.
16:9TV: For TV with an aspect ratio of 16:9.

SYSTEM

The “ SYSTEM” functions which are set when the Power Switch is set to “REC” are also applied when the Power Switch is set to “PLAY”.
[ ] = Factory-preset

MELODY

OFF: Even though not heard while shooting, shutter sound is recorded on the tape.
[ON]: A melody sounds when any operation is performed. It also activates the shutter sound effect. (☞ pg. 27, 38)

CAM RESET

[RETURN]: Does not reset all settings to the factory-preset.
EXECUTE: Resets all settings to the factory-preset.

PRIORITY

[LCD]: The image is displayed on the LCD monitor when the viewfinder is pulled out while the LCD monitor is opened.
FINDER: The image is displayed in the viewfinder when the viewfinder is pulled out while the LCD monitor is opened.

REMOTE

OFF: Disables the remote control operations.
[ON]: Enables the remote control operations.

DISPLAY

- The following menu settings can be changed only when the Power Switch is set to “REC”.
- The DISPLAY settings except “BRIGHT” and “LANGUAGE” are effective only for shooting.

[ ] = Factory-preset

BRIGHT

☞ pg. 18, “Brightness Adjustment Of The Display”

CLOCK ADJ.

☞ pg. 17, “Date/Time Settings”

LANGUAGE

[ENGLISH] / **FRANÇAIS** / **DEUTSCH** / **ESPAÑOL** / **ITALIANO** / **NEDERLANDS** / **PORTUGUÊS** / **РУССКИЙ** / عربي / فارسى / **B.MELAYU** / **BHS.INDO** / ไทย / हिंदी / 汉语 / 中文

The language setting can be changed. (☞ pg. 17)

DATE/TIME

[OFF]: The date/time does not appear.
ON: The date/time is always displayed.

- The date indication can also be turned on/off by pressing the **DISPLAY** Button on the remote control. (☞ pg. 24, 43)

ON SCREEN

LCD: Keeps the camcorder’s display (except the date, time and time code) from appearing on the connected TV screen.
[LCD/TV]: Makes the camcorder’s display appear on screen when the camcorder is connected to a TV.

TIME CODE

[OFF]: Time code is not displayed.
ON: Time code is displayed on the camcorder and on the connected TV. Frame numbers are not displayed during recording. (☞ pg. 22)

DEMO MODE

OFF: Automatic demonstration will not take place.
[ON]: Demonstrates certain functions such as Wipe/Fader and Effects, etc., and can be used to confirm how these functions operate.
Demonstration starts in the following cases:

- When the Menu Screen is closed after “DEMO MODE” is turned “ON”.
- With “DEMO MODE” set to “ON”, if there is no operation for about 3 minutes after the Power Switch is set to “REC”.
- Performing any operation during the demonstration stops the demonstration temporarily. If no operation is performed for more than 3 minutes after that, the demonstration will resume.

NOTES:

- If a cassette is in the camcorder, the demonstration cannot be turned on.
- “DEMO MODE” remains “ON” even if the camcorder power is turned off.

DSC

[ ] = Factory-preset

QUALITY

[FINE] / **STANDARD**
The Picture Quality mode can be selected to best match your needs. Two Picture Quality modes are available: FINE ( ) and STANDARD ( ) (in order of quality).

NOTE:
The number of storable images depends on the selected picture quality as well as the composition of the subjects in the images and the type of memory card being used. (☞ pg. 27)

IMAGE SIZE

640 x 480 / **1280 x 768** / **[1280 x 960]**
The Image Size mode can be selected to best match your needs. (☞ pg. 27)

NOTE:
The setting can be changed only when the **VIDEO/MEMORY** Switch is set to “MEMORY”.

REC SELECT

[(TAPE)]: When Snapshot recording is performed with the **VIDEO/MEMORY** Switch set to “VIDEO”, still images are recorded only onto the tape.
→ /→ (TAPE/CARD): When Snapshot recording is performed with the **VIDEO/MEMORY** Switch set to “VIDEO”, still images are recorded not only onto the tape but also in the memory card (640 x 480 pixels).

Playback Menus

[ ] = Factory-preset

SOUND MODE and NARRATION
During tape playback, the camcorder detects the sound mode in which the recording was made, and plays the sound back. Select the type of sound to accompany your playback picture. According to the menu access explanation on page 32, select “SOUND MODE” or “NARRATION” from the Menu Screen and set it to the desired parameter.

The setting below are effective only for video playback except “BRIGHT”, “16:9” and “REC MODE”.
The parameters (except “OFF” in ON SCREEN, SOUND MODE and NARRATION settings) are the same as in the description on page 33, 35.

REC MODE [SP]* / LP

Allows you to set the video recording mode (SP or LP) depending on your preference.
*SP indicator does not appear on the screen.

SOUND MODE

[STEREO]: Sound is output on both “L” and “R” channels in stereo.
SOUND L : Sound from the “L” channel is output.
SOUND R : Sound from the “R” channel is output.

NARRATION

[OFF]: Original sound is output on both “L” and “R” channels in stereo.
ON: Dubbed sound is output on both “L” and “R” channels in stereo. (☞ pg. 46)
MIX: Original and dubbed sounds are combined and output in stereo on both “L” and “R” channels.

S/AV INPUT

[OFF]: Disables audio/video signal input from the S/AV connector. (☞ pg. 43)
ON: Enables audio/video signal input from the S/AV connector. (☞ pg. 43)

BRIGHT

☞ pg. 18, “Brightness Adjustment Of The Display”

DATE/TIME

[OFF]: The DATE/TIME does not appear.
ON: The DATE/TIME is always displayed.

ON SCREEN OFF / [LCD] / LCD/TV

When set to “OFF”, the camcorder’s display disappears.

TIME CODE [OFF] / ON

☞ pg. 22, “Time Code”

16:9

To enable your tv to display images in 16:9 wide mode, set the tv screen size correctly.
[4:3TV]: For TV with an aspect ratio of 4:3.
16:9TV: For TV with an aspect ratio of 16:9.

LED Light

LED Light can be used to brighten the subject in the dark place during video recording or D.S.C. shooting.



LED Light

1 Press **LIGHT** repeatedly to change the setting.

OFF: Turns off the light.
ON: The light is on always. (☼ appears.)
AUTO: The light turns on automatically when dark. (☼A appears.)

2 Press the Recording Start/Stop Button to start video recording or **SNAPSHOT** to shoot a still image.

NOTES:

- Be careful not to point the LED Light directly to eyes.
- If the light does not reach the subject when the LED Light setting is “ON”, the Night-Scope function will be activated, and makes it possible to shoot the subject brighter.
- There is a difference in the brightness of the images shot between the center area which is illuminated by the LED Light and the surrounding areas (which will be darker).
- Since subjects are shot at a reduced shutter speed when the LED Light setting is “ON”, they will appear slightly blurred.

Live Slow

This feature is useful for recording or playing back precious or hard-to-see moments at a slow speed. Sound is recorded and played back in real time.

1 Set the **VIDEO/MEMORY** Switch to “VIDEO”.

2 Set the recording mode to “M”. (☞ pg. 16)

3 Select and set “SNAP/SLOW” to “SLOW”. (☞ pg. 32, 34) The Live Slow indicator “” appears.

4 Press **SNAPSHOT** (SLOW) during recording or playback.

- The moving pictures are divided into four frames. They are recorded or played back for 1.5 seconds, and then normal recording or playback resumes.
- This feature is effective when the recording mode selection is set to both “A” or “M”.

NOTE:

Available only when the **VIDEO/MEMORY** Switch is set to “VIDEO”.

Wide Mode

This camcorder allows you to choose the type of image output format for video recording.

1 Set the Power Switch to “REC”.

2 Press **16:9** button repeatedly to choose your selection.



[4:3]: Records with no change in the screen ratio. For playback on a TV with a normal screen ratio. When using this mode on a TV with a normal screen ratio, refer to your TV’s instruction manual.
16:9: For playback on TVs with an aspect ratio of 16:9. Naturally expands the image to fit the screen without distortion. The “16:9” indicator appears. When using this mode, refer to your wide-screen TV’s instruction manual. During playback/recording on 4:3 TVs/LCD monitor/viewfinder, select “4:3TV” in “16:9” (☞ pg. 34, 36) to prevent vertical elongated images.
[ ] = Factory-preset

NOTES:

- Available only when the **VIDEO/MEMORY** Switch is set to “VIDEO”.
- Still images are recorded at 4:3 mode. They cannot be recorded at 16:9 mode.

Night-Scope

Makes dark subjects or areas even brighter than they would be under good natural lighting. Although the recorded image is not grainy, it may look as if it is strobing due to the slow shutter speed.

1 Set the Power Switch to "REC".

2 Set the recording mode to "M". (☞ pg. 16)

3 Press **NIGHT** so that the Night-Scope indicator "0,0" appears.

- The shutter speed is automatically adjusted to provide up to 30 times sensitivity.
- "A" appears beside "0,0" while the shutter speed is being automatically adjusted.

To deactivate Night-Scope

Press **NIGHT** again so that the Night-Scope indicator disappears.

NOTES:

- During Night-Scope, "GAIN UP" or "DIS" in SETTING Menu (☞ pg. 33, 34) cannot be activated.
- Night-Scope cannot be activated simultaneously with "SNOW" or "SPORTS" of "PROGRAM AE", or all modes of "SHUTTER". (☞ pg. 42).
- During Night-Scope, it may be difficult to bring the camcorder into focus. To prevent this, use of a tripod is recommended.

Snapshot (Record Still Image On Tape)

This feature lets you record still images that look like photographs onto a tape.

1 Set the **VIDEO/MEMORY** Switch to "VIDEO".

2 Set the Power Switch to "REC".

3 Set the recording mode to "M". (☞ pg. 16)

4 Select "▶" and set "SNAP/SLOW" to "SNAP". (☞ pg. 32, 34)

5 Press **SNAPSHOT**.

- There is the sound effect of a shutter closing.
- The "PHOTO" indication appears and a still image will be recorded for approx. 5 seconds, then the camcorder re-enters the Record-Standby mode.
- You can perform Snapshot also during recording. A still image will be recorded for approx. 5 seconds, then the normal recording resumes.
- Snapshot is effective when the recording mode selection is set to both "A" or "M".
- Snapshot mode cannot be used when the 16:9 Wide mode (16:9 indicator) is selected.

Motor Drive Mode

Keeping **SNAPSHOT** pressed in step **5** provides an effect similar to serial photography. (Interval between still images: approx. 1 second)

- The Motor Drive mode is disabled when "REC SELECT" is set to "▶/▶M". (☞ pg. 35)

Manual Focus

The camcorder's Full Range AF system offers continuous shooting ability from close-up (as close as approx. 5 cm to the subject) to infinity. However, correct focus may not be obtained depending on the shooting condition. In this case, use the manual focus mode.

1 Set the Power Switch to "REC".

2 Set the recording mode to "M". (☞ pg. 16)

3 Press **FOCUS**. The manual focus indicator appears.



Manual focus indicator

4 Press < or > to focus on a subject.

- When the focus level cannot be adjusted any further or closer, "▲" or "👤" will blink.

5 Press **SET**. Focus adjustment is complete.

To reset to Auto Focus

Press **FOCUS** twice.

Manual focus is recommended in situations listed below.

- When two subjects overlap in the same scene.
- When illumination is low.*
- When the subject has no contrast (difference in brightness and darkness), such as a flat, one-color wall, or a clear, blue sky.*
- When a dark object is barely visible in the LCD monitor or the viewfinder.*
- When the scene contains minute patterns or identical patterns that are regularly repeated.
- When the scene is affected by sunbeams or light reflecting off the surface of a body of water.
- When shooting a scene with a high-contrast background.

* The following low-contrast warnings appear blinking: ▲, ◀, ▶ and 👤.

Exposure Control

Manual exposure control is recommended in the following situations:

- When shooting using reverse lighting or when the background is too bright.
- When shooting on a reflective natural background such as at the beach or when skiing.
- When the background is overly dark or the subject is bright.

1 Set the Power Switch to "REC".

2 Set the recording mode to "M". (☞ pg. 16)

3 Set "EXPOSURE" to "MANUAL" in FUNCTION Menu. (☞ pg. 32)

- The exposure control menu appears.

4 To brighten the image, press ∧. To darken the image, press ∨. (maximum ±6)

- +3 exposure has the same effect as the backlight compensation. (☞ pg. 40)
- –3 exposure has the same effect as when "PROGRAM AE" is set to "SPOTLIGHT". (☞ pg. 42)

Operation Mode	VIDEO	MEMORY
Exposure Level	±0	±0EV
	±1	±0.3EV
	±2	±0.7EV
	±3	±1.0EV
	±4	±1.3EV
	±5	±1.7EV
	±6	±2.0EV

5 Press **SET** or >. Exposure adjustment is complete.

To return to automatic exposure control
Select "AUTO" in step **3**.

NOTES:

- You cannot use the manual exposure control at the same time when "PROGRAM AE" is set to "SPOTLIGHT" or "SNOW" (☞ pg. 42), or with the backlight compensation.
- If the adjustment does not cause any visible change in brightness, set "GAIN UP" to "AUTO". (☞ pg. 32, 34)

Iris Lock

Like the pupil of the human eye, the iris contracts in well-lit environments to keep too much light from entering, and dilates in dim environments to allow in more light.
Use this function in the following situations:

- When shooting a moving subject.
- When the distance to the subject changes (so its size in the LCD monitor or the viewfinder changes), such as when the subject is backing away.
- When shooting on a reflective natural background such as at the beach or when skiing.
- When shooting objects under a spotlight.
- When zooming.

1 Set the Power Switch to "REC".

2 Set the recording mode to "M". (☞ pg. 16)

3 Set "EXPOSURE" to "MANUAL" in FUNCTION Menu. (☞ pg. 32)

- The exposure control menu appears.

4 Adjust zoom so that the subject fills the LCD monitor or the viewfinder, then press and hold **SET** or > for over 2 seconds. The exposure control indicator and the "L" indication appears.

5 Press **SET** or >. The iris is locked.

6 Press **MENU**. The Menu Screen closes. The "L" indication appears.

To return to automatic iris control
Select "AUTO" in step **3**.

- The exposure control indicator and "L" disappear.

To lock the exposure control and the iris
After step **3**, adjust the exposure by pressing ∧ or ∨. Then lock the iris in steps **4** – **6**. For automatic locking, select "AUTO" in step **3**. The exposure control and the iris become automatic.

Backlight Compensation

Backlight compensation brightens the subject quickly.
With simple operation, backlight compensation feature brightens the dark subject portion by increasing the exposure.

1 Set the Power Switch to "REC".

2 Press **BACKLIGHT** so that the Backlight Compensation indicator "" appears.

To cancel Backlight Compensation
Press **BACKLIGHT** twice so that the "" indicator disappears.

NOTE:
Using Backlight Compensation may cause the light around the subject to become too bright and the subject to become white.

Spot Exposure Control

Selection of a spot metering area enables more precise exposure compensation. You can select one of the three metering areas on the LCD monitor/viewfinder.

1 Set the Power Switch to "REC".

2 Set the recording mode to "M". (☞ pg. 16)

3 Press **BACKLIGHT** twice so that the Spot Exposure Control indicator "" appears.
- A spot metering area frame appears at the centre of the LCD monitor/viewfinder.

4 Press < or > to select the desired spot metering area frame.

5 Press **SET**.
- Spot Exposure Control is engaged.
- Exposure is adjusted to make the brightness of the selected area most appropriate.

To lock the iris

After step **4**, press and hold **SET** over 2 seconds. The "L" indication appears and the iris is locked.

To cancel Spot Exposure Control

Press **BACKLIGHT** once so that the "" indicator disappears.

NOTES:
- You cannot use the Spot Exposure Control at the same time with following functions.
  - "16:9" in "WIDE MODE" (☞ pg. 37)
  - "STROBE" in EFFECT (☞ pg. 42)
  - Digital Zoom (☞ pg. 21)
- Depending on the shooting location and condition, optimum result may not be attained.

White Balance Adjustment

The white balance refers to the correctness of colour reproduction under various lighting. If the white balance is correct, all other colours will be accurately reproduced.
The white balance is usually adjusted automatically. However, more advanced camcorder operators control this function manually to achieve a more professional colour/tint reproduction.

To change the setting
Set "W. BALANCE" to the desired mode. (☞ pg. 32)
- The selected mode indicator except "AUTO" appears.

[AUTO]: White balance is adjusted automatically.

MWB: Adjust the white balance manually when shooting under various types of lighting. (☞ "Manual White Balance Adjustment", pg. 41)

FINE: Outdoors on a sunny day.

CLOUD: Outdoors on a cloudy day.

[ ] = Factory-preset

To return to automatic white balance
Set "W. BALANCE" to "AUTO". (☞ pg. 32)

Manual White Balance Adjustment

Adjust the white balance manually when shooting under various types of lighting.



White paper

1 Set the Power Switch to "REC".

2 Set the recording mode to "M". (☞ pg. 16)

3 Hold a sheet of plain white paper in front of the subject. Adjust zoom or position yourself so that the white paper fills the screen.

4 Select FUNCTION Menu. (☞ pg. 33)

5 Select "MWB" in "WB W. BALANCE" menu (☞ pg. 33), then press and hold **SET** or > until begins blinking.

- When the setting is completed, stops blinking.

6 Press **SET** or > to engage the setting.

7 Press **MENU**. The Menu Screen closes and the Manual White Balance indicator is displayed.

NOTES:

- In step **3**, it may be difficult to focus on the white paper. In such a case, adjust focus manually. (☞ pg. 38)
- A subject can be shot under various types of lighting conditions indoors (natural, fluorescent, candlelight, etc.). Because the colour temperature is different depending on the light source, the subject tint will differ depending on the white balance settings. Use this function for a more natural result.
- Once you adjust white balance manually, the setting is retained even if the power is turned off or the battery removed.

Wipe Or Fader Effects

These effects let you make pro-style scene transitions. Use them to spice up the transition from one scene to the next.

Wipe or Fader works when video recording is started or stopped.

1 Set the **VIDEO**/**MEMORY** Switch to "VIDEO".

2 Set the Power Switch to "REC".

3 Set the recording mode to "M". (☞ pg. 16)

4 Set "WIPE/FADER" in FUNCTION Menu. (☞ pg. 33)

- The WIPE/FADER menu disappears and the effect is reserved.
- The selected effect indicator appears.

5 Press the Recording Start/Stop Button to activate the Fade-in/out or Wipe-in/out.

To deactivate the selected effect

Select "OFF" in step **4**. The effect indicator disappears.

NOTE:

You can extend the length of a Wipe or Fader by pressing and holding the Recording Start/Stop Button.

WIPE/FADER

OFF: Disables the function. (Factory-preset)

WHITE WH: Fade in or out with a white screen.

BLACK BK: Fade in or out with a black screen.

SLIDE : Wipe in from right to left, or wipe out from left to right.

SCROLL : The scene wipes in from the bottom to the top of a black screen, or wipes out from top to bottom, leaving a black screen.

Program AE, Effects And Shutter Effects

1 Set the Power Switch to "REC".

2 Set the recording mode to "M". (☞ pg. 16)

3 Set "EFFECT", "PROGRAM AE" or "SHUTTER" in FUNCTION Menu. (☞ pg. 33)

- The EFFECT, PROGRAM AE or SHUTTER menu disappears and the selected effect is activated.
- The selected effect indicator appears.

To deactivate the selected effect
Select "OFF" in step **3**. The effect indicator disappears.

NOTES:

- Program AE, Effects and Shutter Effects cannot be changed during recording.
- Some modes of Program AE and Shutter Effects cannot be used during Night-Scope.
- When a subject is too bright or reflective, a vertical streak may appear (smear phenomenon). Smear phenomenon tends to occur when "SPORTS" or any mode of "SHUTTER 1/500 – 1/4000" is selected.

EF EFFECT

OFF: Disables the function. (Factory-preset)

SEPIA : Recorded scenes have a brownish tint like old photos.

MONOTONE B/W : Like classic black and white films, your footage is shot in B/W.

CLASSIC* : Gives recorded scenes a strobe effect.

STROBE* : Your recording looks like a series of consecutive snapshots.

* Not available for still image recording.

PROGRAM AE

OFF: Disables the function. (Factory-preset)

SPORTS
(Variable Shutter Speed: 1/250 – 1/4000): This setting allows fast-moving images to be captured one frame at a time, for vivid, stable slow-motion playback. The faster the shutter speed, the darker the picture becomes. Use the shutter function under good lighting conditions.

SNOW : Compensates for subjects that may otherwise appear too dark when shooting in extremely bright surroundings such as in the snow.

SPOTLIGHT : Compensates for subjects that may otherwise appear too bright when shooting under extremely strong direct lighting such as spotlights.

TWILIGHT : Makes evening scenes look more natural. White Balance (☞ pg. 40) is automatically set to "☀", but can be changed to your desired setting. When Twilight is chosen, the camcorder automatically adjusts the focus from approx. 10 m (32 ft) to infinity. From less than 10 m, adjust the focus manually.

SHUTTER

OFF: Disables the function. (Factory-preset)

1/50 **SHUTTER 1/50**: The shutter speed is fixed at 1/50th of a second. Black bands that usually appear when shooting a TV screen become narrower.

1/120 **SHUTTER 1/120**: The shutter speed is fixed at 1/120th of a second. The flickering that occurs when shooting under a fluorescent light or mercury-vapour lamp is reduced.

SHUTTER 1/500/**SHUTTER 1/4000:** These settings allow fast-moving images to be captured one frame at a time, for vivid, stable slow-motion playback by fixing shutter speed variables. Use these settings when an automatic adjustment does not work well, using **SPORTS** mode. The faster the shutter speed, the darker the picture becomes. Use the shutter function under good lighting conditions.

Dubbing To Or From A VCR



❶ Yellow to VIDEO IN or OUT
❷ Red to AUDIO R IN* or OUT
❸ White to AUDIO L IN* or OUT
❹ To S-VIDEO IN or OUT (Connect when your TV/VCR has an S-VIDEO IN/OUT connector. In this case, it is not necessary to connect the yellow video cable).

* Not required for watching still images only.

NOTE:
The S-Video cable is optional. Be sure to use the YTU94146A S-Video cable. Consult the JVC Service Sentre described on the sheet included in the package for details on its availability. Make sure to connect the end with a core filter to the camera. The core filter reduces interference.

To use this camcorder as a player

1 Following the illustrations, connect the camcorder and the VCR's input connectors.
2 Start playback on the camcorder. (☞ pg. 23)
3 At the point you want to start dubbing, start recording on the VCR. (Refer to the VCR's instruction manual.)
4 To stop dubbing, stop recording on the VCR, then stop playback on the camcorder.

NOTES:
- **It is recommended to use the AC Adapter as the power supply instead of the battery pack. (☞ pg. 15)**
- To choose whether or not the following displays appear on the connected TV
  - Date/time
    Set "DATE/TIME" to "ON" or "OFF". (☞ pg. 32, 36) Or, press **DISPLAY** on the remote control to turn on/off the date indication.
  - Time code
    Set "TIME CODE" to "OFF" or "ON". (☞ pg. 32, 36)
  - Indications other than date/time and time code
    Set "ON SCREEN" to "OFF", "LCD" or "LCD/TV". (☞ pg. 32, 36)

To use this camcorder as a recorder

1 Following the illustrations, connect the camcorder and the VCR's output connectors.
2 Set "REC MODE" to "SP" or "LP". (☞ pg. 33)
3 Set the camcorder's Power Switch to "PLAY"
4 Set "S/AV INPUT" to "ON". (☞ pg. 36)
5 Press the Recording Start/Stop Button to engage the Record-Pause mode.
- The " **A/V IN** " or " **S IN** " iindication appears on the screen.

6 Start playback on the player.
7 At the point you want to start dubbing, press the Recording Start/Stop Button to start dubbing. The ✪ indication rotates.
8 Press the Recording Start/Stop Button again to stop dubbing. The ✪ indication stops rotating.
9 Press ■ to return to the normal playback mode.

NOTES:
- After dubbing, set "S/AV INPUT" back to "OFF".
- Analogue signals can be converted to digital signals with this procedure.
- It is also possible to dub from another camcorder.

Dubbing To Or From A Video Unit Equipped With A DV Connector (Digital Dubbing)

It is also possible to copy recorded scenes from the camcorder onto another video unit equipped with a DV connector. Since a digital signal is sent, there is little, if any, image or sound deterioration.



Video unit equipped with DV connector

To use this camcorder as a player

1 Make sure all units are turned off.

2 Connect this camcorder to a video unit equipped with a DV input connector using a DV cable as shown in the illustration.

3 Start playback on the camcorder. (☞ pg. 23)

4 At the point you want to start dubbing, start recording on the video unit. (Refer to the video unit's instruction manual.)

5 To stop dubbing, stop recording on the video unit, then stop playback on this camcorder.

NOTES:

- **It is recommended to use the AC Adapter as the power supply instead of the battery pack. (☞ pg. 15)**
- If a blank portion or disturbed image is played back on the player during dubbing, the dubbing may stop so that an unusual image is not dubbed.
- Even though the DV cable is connected correctly, sometimes the image may not appear in step **4**. If this occurs, turn off the power and make connections again.
- If "Playback Zoom" (☞ pg. 26) or "Playback Special Effects" (☞ pg. 26) is attempted or **SNAPSHOT** is pressed during playback, only the original playback image recorded on the tape is output from the DV IN/OUT connector.
- **When using a DV cable, be sure to use the optional JVC VC-VDV204U DV cable.**

To use this camcorder as a recorder

1 Make sure all units are turned off.

2 Connect this camcorder to a video unit equipped with a DV output connector using a DV cable as shown in the illustration.

3 Set the camcorder's Power Switch to "PLAY".

4 Set "REC MODE" to "SP" or "LP". (☞ pg. 36)

5 Start playback on the player.

6 Press the Recording Start/Stop Button to engage the Record-Pause mode.

- The " DV IN " indication appears on the screen.

7 At the point you want to start dubbing, press the Recording Start/Stop Button to start dubbing. The ◆ indication rotates.

8 Press the Recording Start/Stop Button again to stop dubbing. The ◆ indication stops rotating.

9 Press ■ to return to the normal playback mode.

NOTES:

- Digital Dubbing is performed in the sound mode recorded on the original tape, regardless of the current "SOUND MODE" setting. (☞ pg. 33)
- If no image is displayed on the LCD monitor, set "S/AV INPUT" to "OFF".

Connection To A Personal Computer

[A] Using USB cable **[B] Using DV cable**



When connecting the camcorder to a PC using a DV cable, make sure to follow the procedure below. Connecting the cable incorrectly may cause malfunctions to the camcorder and/or the PC.

- Connect the DV cable first to the PC, and then to the camcorder.
- Connect the DV cable (plugs) correctly according to the shape of the DV connector.

[A] Using USB cable

It is possible to transfer still images stored on a memory card to a PC.

[B] Using DV cable

It is also possible to transfer still/moving images to a PC with a DV connector by using the provided software, software equipped with the PC or commercially available software.
If you are using a Windows® XP, you can use Windows® Messenger to conduct video conferences over the Internet, using a camcorder. For details, refer to the help for the Windows® Messenger.

NOTES:

- Refer to "SOFTWARE INSTALLATION AND USB CONNECTION GUIDE" for the bundled software and drivers.
- **It is recommended to use the AC Adapter as the power supply instead of the battery pack. (☞ pg. 15)**
- **Never connect the USB cable and the DV cable simultaneously to the camcorder. Connect only the cable you wish to use to the camcorder.**
- **When using a DV cable, be sure to use the optional JVC VC-VDV206U or VC-VDV204U DV cable depending on the type of DV connector (4 or 6 pins) on the PC.**
- If the PC connected to the camcorder via the USB cable is not powered, the camcorder does not enter the USB mode.
- The date/time information cannot be captured into the PC.
- Refer to the instruction manuals of the PC and Software.
- The still images can also be transferred to a PC with a DV connector-equipped capture board.
- The system may not work properly depending on the PC or capture board you are using.

"USB" and/or " ⬅▬➡ " appears on the LCD monitor while the PC is accessing data in the camcorder or the camcorder is transferring a file to the PC.
NEVER disconnect the USB cable while " ⬅▬➡ " is displayed on the LCD monitor since this can result in product damage.

Audio Dubbing

The audio track can be customised only when recorded in the 12-BIT and SP modes.
(☞ pg. 33)

- Use the provided remote control.



1 Play back the tape to locate the point where editing will start, then press **PAUSE** (❚❚).

2 While holding **A. DUB** (⇄) on the remote control, press **PAUSE** (❚❚). The "❚❚⇄" indicator appears.

3 Press **PLAY** (►), then begin "narrating". Speak into the microphone.

- To pause dubbing, press **PAUSE** (❚❚).

4 To end Audio Dubbing, press **PAUSE** (❚❚), then **STOP** (■).

To hear the dubbed sound during playback
Set "NARRATION" to "ON" or "MIX".
(☞ pg. 32, 36)

NOTES:

- Sound is not heard from the speaker during Audio Dubbing.
- When editing onto a tape that was recorded at 12-BIT, the old and new soundtracks are recorded separately.
- If you dub onto a blank space on the tape, the sound may be disrupted. Make sure you only edit recorded areas.
- If feedback or howling occurs during TV playback, move the camcorder's microphone away from the TV, or turn down the TV's volume.
- If you change from 12-BIT to 16-BIT in mid-recording and then use the tape for Audio Dubbing, it is not effective from the point where 16-BIT recording began.
- During Audio Dubbing, when the tape moves to scenes recorded in the LP mode, scenes recorded in 16-BIT audio or a blank portion, Audio Dubbing stops.

Insert Editing

You can record a new scene into a previously recorded tape, replacing a section of the original recording with minimal picture distortion at the in and out points. The original audio remains unchanged.

- Use the provided remote control.

NOTES:

- Before performing the following steps, make sure that "TIME CODE" in both Recording and Playback Menus is set to "ON". (☞ pg. 32, 35, 36)
- Insert Editing is not possible on a tape recorded in the LP mode or on a blank portion of a tape.

1 Play back the tape, locate the Edit-Out point and press **PAUSE** (❚❚). Confirm the time code at this point. (☞ pg. 22)

2 Press **REW** (◄◄) until the Edit-In point is located, then press **PAUSE** (❚❚).

3 Press and hold **INSERT** (⟲) on the remote control, then press **PAUSE** (❚❚). The "❚❚⟲" indicator and the Time Code (min.:sec.) appear and the camcorder enters Insert-Pause mode.

4 Press **START/STOP** to begin editing.

- Confirm the insert at the time code you checked in step **1**.
- To pause editing, press **START/STOP**. Press it again to resume editing.

5 To end Insert Editing, press **START/STOP**, then **STOP** (■) on the remote control.

NOTES:

- Program AE, Effects and Shutter Effects (☞ pg. 42) can be used to spice up the scenes being edited during Insert Editing.
- During Insert Editing, the date and time information changes.
- If you perform Insert Editing onto a blank space on the tape, the audio and video may be disrupted. Make sure you only edit recorded areas.
- During Insert Editing, when the tape moves to scenes recorded in the LP mode or a blank portion, Insert Editing stops. (☞ pg. 50)

If, after following the steps in the chart below, the problem still exists, please consult your nearest JVC dealer.

The camcorder is a microcomputer-controlled device. External noise and interference (from a TV, a radio, etc.) might prevent it from functioning properly. In such cases, first disconnect its power supply unit (battery pack, AC Adapter, etc.) and wait a few minutes; and then re-connect it and proceed as usual from the beginning.

Power

No power is supplied.

- The power is not connected properly.
➜Connect the AC Adapter securely. (☞ pg. 15)
- The battery pack is not attached firmly.
➜Detach the battery pack once again and re-attach it firmly. (☞ pg. 15)
- The battery is dead.
➜Replace the dead battery with a fully charged one. (☞ pg. 15)

Video and D.S.C. Recording

Recording cannot be performed.

- The tape's erase protection tab is set to "SAVE".
➜Set the tape's erase protection tab to "REC". (☞ pg. 19)
- "TAPE END" appears.
➜Replace with new cassette. (☞ pg. 19)
- The cassette holder cover is open.
➜Close the cassette holder cover.

When shooting a subject illuminated by bright light, vertical lines appear.

- This is not a malfunction.

When the screen is under direct sunlight during shooting, the screen becomes red or black for an instant.

- This is not a malfunction.

During recording, the date/ time does not appear.

- "DATE/TIME" is set to "OFF".
➜Set "DATE/TIME" to "ON". (☞ pg. 35, 36)

The LCD monitor or viewfinder indications blink.

- Effects and "DIS" functions that cannot be used together are selected at the same time.
➜Re-read the sections covering Effects and "DIS". (☞ pg. 32, 33, 42)

Digital Zoom does not work.

- 15X optical zoom is selected.
➜Set "ZOOM" to "60X" or "700X". (☞ pg. 34)
- The **VIDEO**/**MEMORY** Switch is set to "MEMORY".
➜Set the **VIDEO**/**MEMORY** Switch to "VIDEO".

Video and D.S.C. Playback

The tape is moving, but there is no picture.

- Your TV has AV input terminals, but is not set to its VIDEO mode.
➜Set the TV to the mode or channel appropriate for video playback. (☞ pg. 24)
- The cassette holder cover is open.
➜Close the cassette holder cover. (☞ pg. 19)

Blocks of noise appear during playback, or there is no playback picture and the screen becomes blue.

➜Clean the video heads with an optional cleaning cassette. (☞ pg. 53)

Advanced features

The focus does not adjust automatically.

- Focus is set to the Manual mode.
➜Set Focus to the Auto mode. (☞ pg. 38)
- The lens is dirty or covered with condensation.
➜Clean the lens and check the focus again. (☞ pg. 51)

Snapshot mode cannot be used.

- The Wide (16:9) mode (16:9 indicator) is selected.
➜Disengage the 16:9 (16:9 indicator) Wide mode. (☞ pg. 32, 34)

The colour of Snapshot looks strange.

- The light source or the subject does not include white. Or there are various different light sources behind the subject.
➜Find a white subject and compose your shot so that it also appears in the frame. (☞ pg. 36)

The image taken using Snapshot is too dark.

- Shooting was performed under backlit conditions.

➜Press **BACKLIGHT**. (☞ pg. 40)

The image taken using Snapshot is too bright.

- The subject is too bright.

➜Set " " to "SPOTLIGHT". (☞ pg. 42)

White Balance cannot be activated.

- The Sepia (SEPIA) or Monotone (MONOTONE) mode is activated.

➜Disengage the Sepia (SEPIA) or Monotone (MONOTONE) mode before setting White Balance. (☞ pg. 42)

The image looks like the shutter speed is too slow.

- When shooting in the dark, the unit becomes highly sensitive to light when "GAIN UP" is set to "AUTO".

➜If you want the lighting to look more natural, set "GAIN UP" to "AGC" or "OFF". (☞ pg. 32, 34)

Other problems

The POWER/CHARGE lamp on the camcorder does not light during charging.

- Charging is difficult in places subject to extremely high/low temperatures.

➜To protect the battery, it is recommended to charge it in places with a temperature of 10°C to 35°C. (☞ pg. 52)

- The battery pack is not attached firmly.

➜Detach the battery pack once again and re-attach it firmly. (☞ pg. 14, 15)

"SET DATE/TIME!" appears.

- The date/time is not set.

➜Set the date/time. (☞ pg. 17)

- The built-in clock battery has run out and the previously set date/time has been erased.

➜Consult your nearest JVC dealer for replacement.

Files stored in the memory card cannot be deleted.

- Files stored in the memory card are protected.

➜Remove protection from the files stored in the memory card and delete them. (☞ pg. 29)

When the image is printed from the printer, a black bar appears at the bottom of the screen.

- This is not a malfunction.

➜By recording with "DIS" de-activated (☞ pg. 32, 33) this can be avoided.

When the camcorder is connected via the DV connector, the camcorder does not operate.

- The DV cable was plugged/unplugged with power turned on.

➜Turn the camcorder's power off and on again, then operate it.

Images on the LCD monitor appear dark or whitish.

- In places subject to low temperature, images become dark due to the characteristics of the LCD monitor. This is not a malfunction.

➜Adjust the brightness and angle of the LCD monitor. (☞ pg. 18, 20)

- When the LCD monitor's fluorescent light reaches the end of its service life, images on the LCD monitor become dark.

➜Consult your nearest JVC dealer.

Coloured bright spots appear all over the LCD monitor or the viewfinder.

- The LCD monitor and the viewfinder are made with high-precision technology. However, black spots or bright spots of light (red, green or blue) may appear constantly on the LCD monitor or the viewfinder. These spots are not recorded on the tape. This is not due to any defect of the unit. (Effective dots: more than 99.99%)

The cassette will not load properly.

- The battery's charge is low.

➜Install a fully charged battery. (☞ pg. 14)

The memory card cannot be removed from the camcorder.

➜Push in the memory card a few more times. (☞ pg. 19)

Picture does not appear on the LCD monitor.

- The viewfinder is pulled out and “PRIORITY” is set to “FINDER”.

➜Push the viewfinder back in or set “PRIORITY” to “LCD”. (☞ pg. 20, 32, 34)

- The LCD monitor’s brightness setting is too dark.

➜Adjust the brightness of the LCD monitor. (☞ pg. 18)

➜If the monitor is tilted upward 180 degrees, open the monitor fully. (☞ pg. 20)

An error indication (01 – 04 or 06) appears.

- A malfunction of some kind has occured. In this case the camcorder’s functions become unusable.

➜☞ pg. 50.

The remote control does not work.

- “REMOTE” is set to “OFF”.

➜Set “REMOTE” to “ON”. (☞ pg. 32, 34)

- The remote control does not point at the remote sensor.

➜Point at the remote sensor. (☞ pg. 25)

- The remote control batteries are exhausted.

➜Replace the batteries with fresh ones. (☞ pg. 25)

Warning Indications

Battery

Displays the battery remaining power.

Remaining power level



High **Exhausted**

As the battery power comes close to nil, the battery remaining power indicator blinks. When the battery power is exhausted, power turns off automatically.

Tape

- Appears if a tape is loaded.
- Blinks when no tape is loaded.

CHECK TAPE’S ERASE PROTECTION TAB

Appears when the erase protection tab is set to “SAVE” while the Power Switch is set to “REC” and the **VIDEO**/**MEMORY** Switch is set to “VIDEO”. (☞ pg. 16)

USE CLEANING CASSETTE

Appears if dirt is detected on the heads during recording. Use an optional cleaning cassette. (☞ pg. 52)

CONDENSATION, OPERATION PAUSED PLEASE WAIT

Appears if condensation occurs. When this indication is displayed, wait more than 1 hour until condensation disappears.

TAPE!

Appears if a tape is not loaded when the Recording Start/Stop Button or **SNAPSHOT** Button is pressed while the Power Switch is set to “REC” and the **VIDEO**/**MEMORY** Switch is set to “VIDEO”.

TAPE END

Appears when the tape ends during recording or playback.

SET DATE/TIME!

- Appears when the date/time is not set. (☞ pg. 17)
- The built-in clock battery has run out and the previously set date/time has been erased. Consult your nearest JVC dealer for replacement.

LENS CAP

Appears for 5 seconds after power is turned on if the lens cap is attached or when it is dark.

A. DUB ERROR!

Appears if Audio Dubbing is attempted on a blank portion of a tape. (☞ pg. 46)

A. DUB ERROR!
<CANNOT DUB ON A LP RECORDED TAPE>
<CANNOT DUB ON A 16BIT RECORDING>
<CHECK TAPE’S ERASE PROTECTION TAB>

- Appears if Audio Dubbing is attempted on a tape recorded in the LP mode. (☞ pg. 46)
- Appears if Audio Dubbing is attempted on a tape recorded in 16-BIT audio. (☞ pg. 46)
- Appears if **A. DUB** (⏏) on the remote control is pressed when the erase protection tab is set to “SAVE”. (☞ pg. 46)

INSERT ERROR!
<CANNOT EDIT ON A LP RECORDED TAPE>
<CHECK TAPE'S ERASE PROTECTION TAB>
<CANNOT EDIT ON A BLANK PORTION>

- Appears if Insert Editing is attempted on a tape recorded in the LP mode. (☞ pg. 46)
- Appears if **INSERT** ( ) on the remote control is pressed when the erase protection tab is set to "SAVE". (☞ pg. 46)
- Appears if Insert Editing is attempted on a blank portion of a tape. (☞ pg. 46)

MEMORY IS FULL

Appears when the memory card's memory is full and shooting is not possible.

HDV

Appears when pictures recorded in the HDV format are detected. The pictures in the HDV format cannot be played back with this camcorder.

?

Appears when playing back a file that is not compatible with DCF or a file with a size that is not compatible with this camcorder.

COPY PROTECTED

Appears if dubbing of copyguarded signals is attempted while this camcorder is being used as a recorder.

MEMORY CARD!

Appears if there is no memory card loaded when the SNAPSHOT Button is pressed while the Power Switch is set to "REC" and the VIDEO/MEMORY Switch is set to "MEMORY".

PLEASE FORMAT

Appears when there is a problem with a memory card and its memory is corrupt, or it has not been initialised. Initialise the memory card. (☞ pg. 31)

NO IMAGES STORED

Appears if there are no image files stored in the memory card when you attempt memory card playback.

CARD ERROR!

Appears when the camcorder does not recognise the loaded memory card. Remove the memory card once and insert it again. Repeat these procedures until no indication appears. If the indication still appears, the memory card is corrupted.

CHECK CARD'S WRITE PROTECTION SWITCH

Appears when you attempt to shoot digital still images when the write protection tab on the SD Memory Card is set to the "LOCK" position.

UNIT IN SAFEGUARD MODE
REMOVE AND REATTACH BATTERY OR DC PLUG

The error indications (01, 02 or 06) show what type of malfunction has occured. When an error indication appears, the camcorder turns off automatically. Remove the power supply (battery, etc.) and wait a few minutes for the indication to clear. When it does, you can resume using the camcorder. If the indication remains, consult your nearest JVC dealer.

UNIT IN SAFEGUARD MODE
EJECT AND REINSERT TAPE

The error indications (03 or 04) show what type of malfunction has occured. When an error indication appears, the camcorder turns off automatically. Eject the cassette once and re-insert it, then check if the indication clears. When it does, you can resume using the camcorder. If the indication remains, consult your nearest JVC dealer.

Cleaning The Camcorder

Before cleaning, turn off the camcorder and remove the battery pack and AC Adapter.

To clean the exterior
Wipe gently with a soft cloth. Put the cloth in diluted mild soap and wring it well to wipe off heavy dirt. Then wipe again with a dry cloth.

To clean the LCD monitor
Wipe gently with a soft cloth. Be careful not to damage the monitor. Close the LCD monitor.

To clean the lens
Blow it with a blower brush, then wipe gently with lens cleaning paper.

To clean the viewfinder lens
Remove dust from the viewfinder using a blower brush.

NOTES:
- Avoid using strong cleaning agents such as benzine or alcohol.
- Cleaning should be done only after the battery pack has been removed or other power units have been disconnected.
- Mold may form if the lens is left dirty.
- When using a cleaner or chemically treated cloth refer to the cautions of each product.
- To clean the viewfinder, please consult your nearest JVC dealer.

Battery Packs

The supplied battery pack is a lithium-ion battery. Before using the supplied battery pack or an optional battery pack, be sure to read the following cautions:



- **To avoid hazards**
  - ...**do not** burn.
  - ...**do not** short-circuit the terminals. When transporting, make sure the provided battery cap is attached to the battery. If the battery cap is misplaced, carry the battery in a plastic bag.
  - ...**do not** modify or disassemble.
  - ...**do not** expose the battery to temperatures exceeding 60°C, as this may cause the battery to overheat, explode or catch fire.
  - ...use only specified chargers.
- **To prevent damage and prolong service life**
  - ...do not subject to unnecessary shock.
  - ...charge in an environment where temperatures are within the tolerances shown in the chart below. This is a chemical reaction type battery — cooler temperatures impede chemical reaction, while warmer temperatures can prevent complete charging.
  - ...store in a cool, dry place. Extended exposure to high temperatures will increase natural discharge and shorten service life.
  - ...fully charge and then fully discharge the battery every 6 months when storing the battery pack over a long period time.
  - ...remove from charger or powered unit when not in use, as some machines use current even when switched off.

The Benefits Of Lithium-Ion Batteries
Lithium-ion battery packs are small but have a large power capacity. However, when one is exposed to cold temperatures (below 10°C), its usage time becomes shorter and it may cease to function. If this happens, place the battery pack in your pocket or other warm, protected place for a short time, then re-attach it to the camcorder.

NOTES:

- It is normal for the battery pack to be warm after charging, or after use.
  Temperature Range Specifications
  Charging: 10°C to 35°C
  Operation: 0°C to 40°C
  Storage: –20°C to 50°C
- The lower the temperature, the longer recharging takes.
- Charging times are for a fully discharged battery pack.

Cassettes

To properly use and store your cassettes, be sure to read the following cautions:

- **During use**
  - ...make sure the cassette bears the Mini DV mark.
  - ...be aware that recording onto prerecorded tapes automatically erases the previously recorded video and audio signals.
  - ...make sure the cassette is positioned properly when inserting.
  - ...do not load and unload the cassette repeatedly without allowing the tape to run at all. This slackens the tape and can result in damage.
  - ...do not open the front tape cover. This exposes the tape to fingerprints and dust.
- **Store cassettes**
  - ...away from heaters or other heat sources.
  - ...out of direct sunlight.
  - ...where they won't be subject to unnecessary shock or vibration.
  - ...where they won't be exposed to strong magnetic fields (such as those generated by motors, transformers or magnets).
  - ...vertically, in their original cases.

Memory Cards

To properly use and store your memory cards, be sure to read the following cautions:

- **During use**
  - ...make sure the memory card bears the SD or MultiMediaCard mark.
  - ...make sure the memory card is positioned properly when inserting.
- **While the memory card is being accessed (during recording, playback, deletion, initialization, etc.)**
  - ...never unload the memory card and never turn off the camcorder.
- **Store memory cards**
  - ...away from heaters or other heat sources.
  - ...out of direct sunlight.
  - ...where they won't be subject to unnecessary shock or vibration.
  - ...where they won't be exposed to strong magnetic fields (such as those generated by motors, transformers or magnets).

LCD Monitor

- **To prevent damage to the LCD monitor, DO NOT**
  - ...push it strongly or apply any shocks.
  - ...place the camcorder with the LCD monitor on the bottom.
- **To prolong service life**
  - ...avoid rubbing it with coarse cloth.
- **Be aware of the following phenomena for LCD monitor use. These are not malfunctions**
  - ...While using the camcorder, the surface around the LCD monitor and/or the back of the LCD monitor may heat up.
  - ...If you leave power on for a long time, the surface around the LCD monitor becomes hot.

Main Unit

- **For safety, DO NOT**
  - ...open the camcorder's chassis.
  - ...disassemble or modify the unit.
  - ...short-circuit the terminals of the battery pack. Keep it away from metallic objects when not in use.
  - ...allow inflammables, water or metallic objects to enter the unit.
  - ...remove the battery pack or disconnect the power supply while the power is on.
  - ...leave the battery pack attached when the camcorder is not in use.
- **Avoid using the unit**
  - ...in places subject to excessive humidity or dust.
  - ...in places subject to soot or steam such as near a cooking stove.
  - ...in places subject to excessive shock or vibration.
  - ...near a television set.
  - ...near appliances generating strong magnetic or electric fields (speakers, broadcasting antennas, etc.).
  - ...in places subject to extremely high (over 40°C) or extremely low (under 0°C) temperatures.
- **DO NOT leave the unit**
  - ...in places of over 50°C.
  - ...in places where humidity is extremely low (below 35%) or extremely high (above 80%).
  - ...in direct sunlight.
  - ...in a closed car in summer.
  - ...near a heater.
- **To protect the unit, DO NOT**
  - ...allow it to become wet.
  - ...drop the unit or strike it against hard objects.
  - ...subject it to shock or excessive vibration during transportation.
  - ...keep the lens directed at extremely bright objects for long periods.
  - ...expose the lens and viewfinder's lens to direct sunlight.
  - ...carry it by holding the LCD monitor or the viewfinder.
  - ...swing it excessively when using the hand strap or the grip.
  - ...swing the soft camera case excessively when the camcorder is inside it.
- **Dirty heads can cause the following problems:**

  - ...No picture during playback.
  - ...Blocks of noise appear during playback.
  - ...During recording or playback, the Head Clog Warning indicator "⊗" appears.
  - ...Recording cannot be performed properly.

In such cases, use an optional cleaning cassette. Insert it and play back. If the cassette is used more than once consecutively, damage to the video heads may result. After the camcorder plays back for about 20 seconds, it stops automatically. Also refer to the cleaning cassette's instructions.
If, after using the cleaning cassette, the problems still exist, consult your nearest JVC dealer.
Mechanical moving parts used to move the video heads and video tape tend to become dirty and worn out over time. In order to maintain a clear picture at all times, periodic check-ups are recommended after using the unit for about 1,000 hours. For periodic check-ups please consult your nearest JVC dealer.

How To Handle A CD-ROM

- Take care not to soil or scratch the mirror surface (opposite to the printed surface). Do not write anything or put a sticker on either the front or back surface. If the CD-ROM gets dirty, gently wipe it with a soft cloth outward from the centre hole.
- Do not use conventional disc cleaners or cleaning spray.
- Do not bend the CD-ROM or touch its mirror surface.
- Do not store your CD-ROM in a dusty, hot or humid environment. Keep it away from direct sunlight.

About moisture condensation

- You have observed that pouring a cold liquid into a glass will cause drops of water to form on the glass' outer surface. This same phenomenon occurs on the head drum of a camcorder when it is moved from a cool place to a warm place, after heating a cold room, under extremely humid conditions or in a place directly subjected to the cool air from an air conditioner.
- Moisture on the head drum can cause severe damage to the video tape, and can lead to internal damage to the camcorder itself.

Serious malfunctioning

If malfunctioning occurs, stop using the unit immediately and consult your local JVC dealer.

The camcorder is a microcomputer-controlled device. External noise and interference (from a TV, a radio, etc.) might prevent it from functioning properly. In such cases, first disconnect its power supply unit (battery pack, AC Adapter, etc.) and wait a few minutes and then re-connect it and proceed as usual from the beginning.

Camcorder

For General

Power supply
DC 11 V (Using AC Adapter)
DC 7.2 V (Using battery pack)
Power consumption
Approx. 2.8 W (3.0 W*) (LCD monitor off, viewfinder on)
Approx. 3.1 W (3.3 W*) (LCD monitor on, viewfinder off)
* Using LED Light
Dimensions (W x H x D)
59 mm x 97 mm x 112 mm (with the LCD monitor closed and the viewfinder pushed back in)
Weight
Approx. 420 g (without battery, cassette and lens cap)
Approx. 500 g (incl. battery, cassette and lens cap)
Operating temperature
0°C to 40°C
Operating humidity
35% to 80%
Storage temperature
–20°C to 50°C
Pickup
1/5" CCD
Lens
F 1.2, f = 3.0 mm to 45 mm, 15:1 power zoom lens
Filter diameter
ø30.5 mm
LCD monitor
2.5" diagonally measured, LCD panel/TFT active matrix system
Viewfinder
Electronic viewfinder with 0.33" colour LCD
Speaker
Monaural
LED Light
Effective distance: 1.5 m

For Digital Video Camera

Format
DV format (SD mode)
Signal format
PAL standard
Recording/Playback format
Video: Digital component recording
Audio: PCM digital recording, 32 kHz 4-channel (12-BIT), 48 kHz 2-channel (16-BIT)
Cassette
Mini DV cassette
Tape speed
SP: 18.8 mm/s, LP: 12.5 mm/s
Maximum recording time (using 80 min. cassette)
SP: 80 min., LP: 120 min.

For Digital Still Camera

Storage media
SD Memory Card/MultiMediaCard
Compression system
JPEG (compatible)
File size
Still image:
3 modes (1280 x 960 pixels / 1024 x 768 pixels / 640 x 480 pixels
Picture quality
2 modes (FINE/STANDARD)
Approximate number of storable images
☞ pg. 27

For Connectors

S
S-Video input:
Y: 0.8 V to 1.2 V (p-p), 75 Ω, analogue
C: 0.2 V to 0.4 V (p-p), 75 Ω, analogue
S-Video output:
Y: 1.0 V (p-p), 75 Ω, analogue
C: 0.3 V (p-p), 75 Ω, analogue
AV
Video input: 0.8 V to 1.2 V (p-p), 75 Ω, analogue
Video output: 1.0 V (p-p), 75 Ω, analogue
Audio input: 300 mV (rms), 50 kΩ, analogue, stereo
Audio output: 300 mV (rms), 1 kΩ, analogue, stereo

AC Adapter

Power requirement
AC 110 V to 240 V~, 50 Hz/60 Hz
Output
DC 11 V ⎓, 1 A

Specifications shown are for SP mode unless otherwise indicated. E & O.E. Design and specifications subject to change without notice.

A

AC Adapter 14
Audio Dubbing 46
Auto/Manual Mode 16

B

Backlight Compensation 40
Battery Pack 14, 15, 52
Blank Search 23

C

Changing The Menu Settings ..... 32 – 36
Charging The Battery Pack 14
Connection To A Personal Computer 45
Connections To A TV Or VCR 24

D

Data Battery 15
Date/Time Settings 17
Deleting Files 30
Demonstration Mode 35
Digital Image Stabilisation (DIS) 33
DPOF Setting
(Digital Print Order Format) 30
Dubbing 43, 44

E

Exposure Control 39

I

Initialising A Memory Card 31
Insert Editing 46
Interface Shooting 21
Iris Lock 39

L

LCD Monitor and Viewfinder 20
LED Light 37
Live Slow 37
Loading A Cassette 19
Loading A Memory Card 19

M

Manual Focus 38
Melody 34
Memory Card 19, 52
Motor Drive Mode 38

N

Night-Scope 38

P

Picture Quality 35
Playback Sound 36
Playback Special Effects 26
Power-Linked Operation 16
Program AE, Effects and Shutter Effects 42

Q

Quick Review 22

R

Recording Capacity
Memory Card 27
Tape 20
Recording Media Selection 35
Remote Control 25
Resetting The File Name 29

S

Slow-Motion Playback 26
Snapshot Mode 34, 38
Sound Mode 33, 36
Speaker Volume 23
Specifications 55
Spot Exposure Control 40

T

Tape Speed (REC MODE) 33, 36
Tele Macro 33
Tele Mode .....
Time Code 22, 35, 36
Tripod Mounting 18
Troubleshooting 47-50

W

Warning Indications 49, 50
White Balance 40
Wide Mode 37
Wipe Or Fader Effects 41

Z

Zooming 21, 26, 34

16:9 34

JVC

© 2006 Victor Company of Japan, Limited

AS Printed in Japan
0406ASR-NF-VP